





Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Bosch alternator	-	-	-	-	GU17712400	1	
2	Hex socket screw M5X45	-	-	-	-	GU98620245	3	
3	Notched washer	-	-	-	-	GU95021105	9	
4	Repairing kit	-	-	-	-	GU17712454	1	
5	Connector 3 vie	-	-	-	-	GU61712500	1	
6	HT cable	-	-	-	-	GU17718350	2	
7	Cap	-	-	-	-	GU14717600	2	
8	Sparkplug cap	-	-	-	-	GU14717400	2	
9	Spark plug	-	-	-	-	GU25717025	2	
10	HT cable	-	-	-	-	GU17718350	2	
11	Wire	-	-	-	-	GU14747700	1	
12	Screw	-	-	-	-	GU98052345	2	
13	Washer	-	-	-	-	GU95100154	2	
14	Spacer	-	-	-	-	GU91180718	2	
15	Washer	-	-	-	-	GU95000206	2	
16	Nut M6x1	-	-	-	-	GU92630106	4	
17	Voltage regulator BOSCH	-	-	-	-	GU29703800	1	
18	Hex screw M6X20	-	-	-	-	GU98054320	1	
19	Hex screw M6X16	-	-	-	-	GU98054316	1	
20	Washer 6,4x12x1,2	-	-	-	-	GU95100141	2	
21	Rubber spacer	-	-	-	-	GU93110060	2	
22	Main switch	-	-	-	-	GU31735360	1	
23	Wire	-	-	-	-	GU14748450	1	
24	Connector	-	-	-	-	GU61712600	1	
25	Cap	-	-	-	-	GU19707100	1	
26	Protection	-	-	-	-	GU19733350	1	
27	Lock hardware kit	-	-	-	-	GU14736850	1	
28	Bosch rectifier	-	-	-	-	GU17704300	1	
29	Cover	-	-	-	-	GU14704205	2	
30	Screw	-	-	-	-	GU98305017	4	
31	Washer 5,25x14x1,5	-	-	-	-	GU95100059	2	
32	Washer	-	-	-	-	GU95000205	4	
33	Nut	-	-	-	-	GU92602205	5	

34	Wire	-	-	-	-	-	GU17748500	1
35	Battery 12V-32AH	-	-	-	-	-	GU14704505	1
36	Float chamber	-	-	-	-	-	GU14707000	1
37	Belt	-	-	-	-	-	GU14704800	1
38	Fixing snap	-	-	-	-	-	GU14705500	1
39	Plug	-	-	-	-	-	GU93180220	1
40	Wire	-	-	-	-	-	GU14748450	1
41	Cap	-	-	-	-	-	GU25706700	1
42	Starter relay	-	-	-	-	-	GU19732500	1
43	Screw	-	-	-	-	-	GU98054214	2
44	Starter motor Valeo	-	-	-	-	-	GU30730711	1
45	Switch assy	-	-	-	-	-	GU14730558	1
46	Starter motor revision kit	-	-	-	-	-	GU14730570	1
47	Screw	-	-	-	-	-	GU98052480	2
49	Washer	-	-	-	-	-	GU95004208	2
50	Nut M8X1,25	-	-	-	-	-	GU92602208	1
51	Contact breaker	-	-	-	-	-	GU17715450	1
52	Gasket	-	-	-	-	-	GU14716400	1
53	Gear	-	-	-	-	-	GU14716200	1
54	Pin	-	-	-	-	-	GU95510318	1
55	Plate	-	-	-	-	-	GU14715700	1
56	Hex screw M8x30	-	-	-	-	-	GU98052430	2
57	Washer 8,4X13X0,8	-	-	-	-	-	GU14615901	2
58	Spacer	-	-	-	-	-	GU91180907	2
59	Cover	-	-	-	-	-	GU14715420	1
60	Contact breaker rev.kit	-	-	-	-	-	GU14719800	1
61	Toolkit	-	-	-	-	-	GU28929940	1
63	Screw	-	-	-	-	-	GU14712459	1




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Fuel tank	-	-	-	-	GU171002651	1	
2	Tank cap	-	-	-	-	GU28103946	1	
3	Tank cover, blank	-	-	-	-	GU141040551	1	
4	Screw	-	-	-	-	GU98054210	2	
5	Locks	-	-	-	-	GU14736856	1	
6	Tab	-	-	-	-	GU18105001	1	
7	Hose clamp	-	-	-	-	GU19104950	1	
8	Decal "Moto Guzzi"	-	-	-	-	GU14917300	2	
9	Clip	-	-	-	-	GU14105100	8	
10	LH fuel cock	-	-	-	-	GU17105461	1	
11	RH fuel cock	-	-	-	-	GU17105460	1	
12	Gasket	-	-	-	-	GU90714103	2	
13	Front mudguard	-	-	-	-	GU144344601	1	
14	Plate	-	-	-	-	GU19436600	4	
15	Spring washer 8x15x0,3	-	-	-	-	GU61270300	4	
16	Nut M8X1,25	-	-	-	-	GU92602208	6	
17	Splash guard	-	-	-	-	GU14438750	1	
18	Hex screw M6X20	-	-	-	-	GU98054320	4	
19	Rubber spacer	-	-	-	-	GU93110060	13	
20	Washer	-	-	-	-	GU95000206	6	
21	Washer 6,4x12x1,2	-	-	-	-	GU95100141	2	
22	Nut M6x1	-	-	-	-	GU92630106	5	
23	Rear mudguard	-	-	-	-	GU174370401	1	
24	Screw	-	-	-	-	GU98052440	2	
25	Spacer	-	-	-	-	GU91180816	2	
27	Plug	-	-	-	-	GU93180105	2	
28	Saddle	-	-	-	-	GU18460650	1	
29	Rod	-	-	-	-	GU17462750	1	
30	Drift	-	-	-	-	GU14103800	4	
31	Screw M8X22	-	-	-	-	GU98054422	2	
32	Spring washer 8x15x0,3	-	-	-	-	GU61270300	2	
33	Nut	-	-	-	-	GU92630108	2	
34	Pillion grab bar	-	-	-	-	GU17464300	1	

35	RH side panel	-	-	-	-	-	GU17476250	1
36	LH side panel	-	-	-	-	a	GU17476365	1
	LH side panel	-	-	-	-	g	GU17476367	1
	LH side panel	-	-	-	-	v	GU17476366	1
37	Rubber spacer	-	-	-	-	-	GU91551082	2
38	Net panel (r)	-	-	-	-	-	GU17925050	1
39	Net panel (l)	-	-	-	-	-	GU17925150	1
40	Plate	-	-	-	-	-	GU39922200	8
41	Name plate "1000 SP"	-	-	-	-	-	GU17922061	2
42	Plate holder support	-	-	-	-	-	GU10474600	1
43	Hex screw M6X16	-	-	-	-	-	GU98054316	1
44	Washer 5,25x14x1,5	-	-	-	-	-	GU95100059	6
45	Screw	-	-	-	-	-	GU98054220	2
47	Nut	-	-	-	-	-	GU92630105	2
48	Rubber spacer	-	-	-	-	-	GU14461400	1
49	Fixing snap	-	-	-	-	-	GU14102600	1
50	Decal set	-	-	-	D1	-	GU17923362	1
51	Washer	-	-	-	-	-	GU95000208	4
52	Spring washer	-	-	-	-	-	GU95021108	2
53	Spring washer 5,3X10X0,5	-	-	-	-	-	GU95129100	4
54	Clamp	-	-	-	-	-	GU141022551	1
55	Rubber spacer	-	-	-	-	-	GU93180706	2
56	Plate	-	-	-	-	-	GU141012551	1
57	Screw	-	-	-	-	-	GU98202525	2
58	Spacer	-	-	-	-	-	GU91180608	2




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Front fairing	-	-	-	-	GU17575442	1	
3	Gasket	-	-	-	-	GU17578960	1	
4	Name plate Moto Guzzi	-	-	-	-	GU39917300	1	
5	Clip	-	-	-	-	GU14105100	2	
6	Windscreen	-	-	-	-	GU17577261	1	
7	Screw	-	-	-	-	GU98260416	8	
8	Washer	-	-	-	-	GU14577850	8	
9	Washer	-	-	-	-	GU95007204	8	
10	Nut	-	-	-	-	GU92601004	8	
11	Fairing lower support	-	-	-	-	GU17578860	1	
12	Screw	-	-	-	-	GU98054314	1	
13	Washer	-	-	-	-	GU95000206	1	
14	Spacer	-	-	-	-	GU91180608	1	
15	Rubber spacer	-	-	-	-	GU91551085	11	
16	Protection	-	-	-	-	GU17571860	1	
17	Screw	-	-	-	-	GU98326016	10	
18	RH front fairing support	-	-	-	-	GU17578660	1	
19	LH front fairing support	-	-	-	-	GU17578661	1	
20	Screw	-	-	-	-	GU98072440	2	
21	Washer	-	-	-	-	GU95007208	2	
22	Spacer	-	-	-	-	GU91180607	8	
23	Rearview mirror	-	-	-	-	GU17769861	2	
24	Screw	-	-	-	-	GU98290513	4	
25	Washer	-	-	-	-	GU95007205	4	
26	Front fairing support	-	-	-	-	GU175708611	1	
27	Screw	-	-	-	-	GU98074420	2	
28	Washer	-	-	-	-	GU95007208	2	
29	Plate	-	-	-	-	GU17451750	1	
30	RH side panel	-	-	-	-	GU175703731	1	
31	LH side panel	-	-	-	-	GU175704731	1	
32	Plate	-	-	-	-	GU17571961	1	
33	LH front fairing support	-	-	-	-	GU175721611	1	
34	Protection	-	-	-	-	GU17573860	2	

35	Spacer	-	-	-	-	-	GU90716104	2
36	Washer 6,5X17X1.5	-	-	-	-	-	GU95100139	6
37	Plate	-	-	-	-	-	GU175705621	1
38	RH protection	-	-	-	-	-	GU17573562	1
39	LH protection	-	-	-	-	-	GU17574562	1
40	Screw	-	-	-	-	-	GU98326016	2
41	Screw	-	-	-	-	-	GU98326016	4
42	O-ring	-	-	-	-	-	GU90706035	8
43	LH clamp	-	-	-	-	-	GU17570563	1




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Front fairing	-	-	-	-	GU17575442	1	
3	Gasket	-	-	-	-	GU17578960	1	
4	Name plate Moto Guzzi	-	-	-	-	GU39917300	1	
5	Clip	-	-	-	-	GU14105100	2	
6	Windscreen	-	-	-	-	GU17577261	1	
7	Screw	-	-	-	-	GU98260416	8	
8	Washer	-	-	-	-	GU14577850	8	
9	Washer	-	-	-	-	GU95007204	8	
10	Nut	-	-	-	-	GU92601004	8	
11	Fairing lower support	-	-	-	-	GU17578860	1	
12	Screw	-	-	-	-	GU98054314	1	
13	Washer	-	-	-	-	GU95000206	1	
14	Spacer	-	-	-	-	GU91180608	1	
15	Rubber spacer	-	-	-	-	GU91551085	11	
16	Protection	-	-	-	-	GU17571860	1	
17	Screw	-	-	-	-	GU98326016	10	
18	RH front fairing support	-	-	-	-	GU17578660	1	
19	LH front fairing support	-	-	-	-	GU17578661	1	
20	Screw	-	-	-	-	GU98072440	2	
21	Washer	-	-	-	-	GU95007208	2	
22	Spacer	-	-	-	-	GU91180607	8	
23	Rearview mirror	-	-	-	-	GU17769861	2	
24	Screw	-	-	-	-	GU98290513	4	
25	Washer	-	-	-	-	GU95007205	4	
26	Front fairing support	-	-	-	-	GU175708611	1	
27	Screw	-	-	-	-	GU98074420	2	
28	Washer	-	-	-	-	GU95007208	2	
29	Plate	-	-	-	-	GU17451750	1	
30	RH side panel	-	-	-	-	GU175703731	1	
31	LH side panel	-	-	-	-	GU175704731	1	
32	Plate	-	-	-	-	GU17571961	1	
33	LH front fairing support	-	-	-	-	GU175721611	1	
34	Protection	-	-	-	-	GU17573860	2	

35	Spacer	-	-	-	-	-	GU90716104	2
36	Washer 6,5X17X1.5	-	-	-	-	-	GU95100139	6
37	Plate	-	-	-	-	-	GU175705621	1
38	RH protection	-	-	-	-	-	GU17573562	1
39	LH protection	-	-	-	-	-	GU17574562	1
40	Screw	-	-	-	-	-	GU98326016	2
41	Screw	-	-	-	-	-	GU98326016	4
42	O-ring	-	-	-	-	-	GU90706035	8
43	LH clamp	-	-	-	-	-	GU17570563	1




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Headlight	-	-	-	-	GU28740533	1	
2	Special screw	-	-	-	-	GU39740302	1	
4	Screw	-	-	-	-	GU39740303	1	
5	Spring	-	-	-	-	GU39740304	1	
6	Pawl	-	-	-	-	GU17740362	1	
7	Adjusting pin	-	-	-	-	GU39740306	1	
8	Snap ring	-	-	-	-	GU19740307	1	
10	Lampholder	-	-	-	-	GU39740530	1	
11	Lamp 12V 45/40W	-	-	-	-	GU93450231	1	
12	Lamp 12V-4W	-	-	-	-	GU93450119	1	
13	Lampholder	-	-	-	-	GU17740468	1	
14	Washer	-	-	-	-	GU95120105	1	
15	Screw	-	-	-	-	GU98054520	1	
16	Self-tap screw	-	-	-	-	GU17740366	1	
17	Rear cap plug	-	-	-	-	GU19740404	1	
18	Main switch	-	-	-	-	GU17740364	1	
19	Taillight assy	-	-	-	-	GU19740900	1	
20	Taillight	-	-	-	-	GU65740900	1	
21	Lamp 12V/5-21W	-	-	-	-	GU93450224	2	
22	Taillight body	-	-	-	-	GU19741000	1	
23	Support	-	-	-	-	GU19741200	1	
24	Taillight lens	-	-	-	-	GU65741700	1	
25	Screw	-	-	-	-	GU35751870	2	
26	Nut	-	-	-	-	GU92602206	2	
27	Washer	-	-	-	-	GU95000206	4	
28	Hex screw M6X16	-	-	-	-	GU98054316	2	
29	Washer 5,3x10x0,5	-	-	-	-	GU95100121	4	
30	Main switch	-	-	-	-	GU17740364	1	
31	Nut M6x1	-	-	-	-	GU92630106	4	
32	Wiring	-	-	-	-	GU17747360	1	




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Front fork	-	-	-	-	GU17490262	1	
2	Lower fork plate	-	-	-	-	GU184940611	1	
3	Hex screw M10X55	-	-	-	-	GU98072555	2	
4	Spacer	-	-	-	-	GU91181016	2	
5	Washer	-	-	-	-	GU95007210	2	
6	Fork upper plate	-	-	-	-	GU17493160	1	
7	Screw	-	-	-	-	GU98612535	2	
8	Steering lock bush	-	-	-	-	GU18516660	1	
9	Washer	-	-	-	-	GU95004208	4	
10	LH sleeve	-	-	-	-	GU185226601	1	
11	RH sleeve	-	-	-	-	GU185225601	1	
12	Stud bolt	-	-	-	-	GU96508021	4	
13	Oil unload plug	-	-	-	-	GU98620312	2	
14	Washer 6,25x10x1,5	-	-	-	-	GU95100116	2	
15	Fork arm	-	-	-	-	GU14525401	2	
16	Plug	-	-	-	-	GU14504502	2	
17	Gasket ring	-	-	-	-	GU90706238	2	
18	Oil seal	-	-	-	-	GU90403449	2	
19	Dust cover	-	-	-	-	GU14524500	2	
20	Fork shock absorber	-	-	-	-	GU14526455	2	
21	Pipe	-	-	-	-	GU14527800	2	
22	Fork pump ring	-	-	-	-	GU14527900	2	
23	Spring	-	-	-	-	GU17526960	2	
24	Return spring	-	-	-	-	GU18526660	2	
25	Spacer	-	-	-	-	GU18527960	2	
26	Circlip	-	-	-	-	GU90271014	2	
27	Lower cup	-	-	-	-	GU14527601	2	
28	Screw	-	-	-	-	GU98622535	2	
29	Gasket	-	-	-	-	GU10528900	2	
30	Screw	-	-	-	-	GU98622422	2	
31	Screw M10X40	-	-	-	-	GU98620540	2	
32	Nut	-	-	-	-	GU92781100	2	
33	RH headlight bracket	-	-	-	-	GU17496160	1	

34	LH headlight bracket	-	-	-	-	-	GU17496260	1
35	Ring	-	-	-	-	-	GU17492700	4
36	Plug	-	-	-	-	-	GU18513460	1
37	Stem plug washer	-	-	-	-	-	GU18513560	1
38	Plug	-	-	-	-	-	GU17517700	1
39	Cup	-	-	-	-	-	GU14494600	1
40	Tap.roller bearing	-	-	-	-	-	GU92249225	2
41	Clearance washer	-	-	-	-	-	GU14516700	1
42	Dust cover	-	-	-	-	-	GU14517000	1
43	Steering shock absorber	-	-	-	-	-	GU03530270	1
44	Washer 5,3x10x0,5	-	-	-	-	-	GU95100121	1
45	Screw	-	-	-	-	-	GU98052325	1
46	Hex screw M6X20	-	-	-	-	-	GU98054320	1
47	Washer	-	-	-	-	-	GU95000206	1
48	Nut M6x1	-	-	-	-	-	GU92630106	1
49	Handlebar collar	-	-	-	-	-	GU17500200	2
50	Screw M8X35	-	-	-	-	-	GU98620435	2
51	Screw	-	-	-	-	-	GU17500760	2
52	Shock absorber	-	-	-	-	-	GU23999290	2
53	Spring	-	-	-	-	-	GU17552361	2
54	Nut M6x1	-	-	-	-	-	GU92630106	2
55	Flat washer	-	-	-	-	-	GU95004215	4
56	Washer	-	-	-	-	-	GU95100337	2
57	Nut	-	-	-	-	-	GU92602210	2
58	Nylon washer	-	-	-	-	-	GU18526560	2
59	Hex screw M8X20	-	-	-	-	-	GU98054420	2




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Swing arm	-	-	-	-	GU185402001	1	
2	Screw	-	-	-	-	GU98052535	1	
3	Washer 10,2x18x2	-	-	-	-	GU95004210	1	
4	Nut	-	-	-	-	GU14547800	2	
5	Spacer	-	-	-	-	GU12547200	2	
6	Pin	-	-	-	-	GU14547001	2	
7	Gasket ring	-	-	-	-	GU90403040	2	
8	Bearing	-	-	-	-	GU92249217	2	
9	Protection collar	-	-	-	-	GU18548000	1	
10	Clamp	-	-	-	-	GU12548401	1	
11	Hose clamp 62/82 mm	-	-	-	-	GU12548201	1	
12	Coupling	-	-	-	-	GU30328031	1	
13	Circlip	-	-	-	-	GU90272062	1	
14	Ball bearing 30x62x16	-	-	-	-	GU92204230	1	
15	Pin	-	-	-	-	GU12555201	2	
16	Transmission complete	-	-	-	-	GU17350250	1	
17	Transmission box, blank	-	-	-	-	GU28350345	1	
18	Stud bolt 8x46	-	-	-	-	GU96508045	4	
19	Washer 8,4X13X0,8	-	-	-	-	GU14615901	4	
20	Nut	-	-	-	-	GU92781081	4	
21	Oil unload plug	-	-	-	-	GU12003702	1	
22	Gasket 20,1x28x2	-	-	-	-	GU95100709	1	
23	Plug	-	-	-	-	GU95980610	2	
24	Gasket	-	-	-	-	GU10528900	2	
25	Gasket ring	-	-	-	-	GU90403850	1	
26	Gasket ring	-	-	-	-	GU12351100	1	
27	Roller bearing 40x55x17	-	-	-	-	GU92254340	1	
28	Drive shaft	-	-	-	-	GU12326300	1	
29	Hose	-	-	-	-	GU12327700	1	
30	Snap ring	-	-	-	-	GU90271020	3	
31	Nut	-	-	-	-	GU30356760	1	
32	Tap.roller bearing 25x5	-	-	-	-	GU92249227	2	
33	Flange	-	-	-	-	GU18352400	1	

34	Gasket 58,42x2,62	-	-	-	-	-	GU90706584	2
35	Spacer	-	-	-	-	-	GU18355100	1
36	Shim 0,1 mm	-	-	-	-	-	GU12355202	2
	Shim 0,15 mm	-	-	-	-	-	GU12355203	11
37	Spacer 1 mm	-	-	-	-	-	GU19355320	2
	Spacer 1,2 mm	-	-	-	-	-	GU19355322	2
	Spacer 1,5 mm	-	-	-	-	-	GU19355325	2
38	Screw M8X25	-	-	-	-	-	GU98054425	8
39	Spring washer 8x15x0,3	-	-	-	-	-	GU61270300	8
40	Plate	-	-	-	-	-	GU95187008	8
41	Flange	-	-	-	-	-	GU17350400	1
42	Gasket	-	-	-	-	-	GU17350700	2
43	Spacer 1,1 mm	-	-	-	-	-	GU17355406	1
	Spacer 1,3 mm	-	-	-	-	-	GU17355410	1
	Spacer 0,9 mm	-	-	-	-	-	GU17355402	1
	Spacer 1,5 mm	-	-	-	-	-	GU17355412	1
	Spacer 0,8 mm	-	-	-	-	-	GU17355400	1
	Spacer 1 mm	-	-	-	-	-	GU17355404	1
	Spacer 1,2 mm	-	-	-	-	-	GU17355408	1
44	Ball bearing 70x110x13	-	-	-	-	-	GU92201070	1
45	Gasket ring	-	-	-	-	-	GU90407085	1
46	Drive flange	-	-	-	-	-	GU17351400	1
47	Bevel gear Z=7/33	-	-	-	-	-	GU17354650	1
48	Screw	-	-	-	-	-	GU12356300	8
49	Safety plate	-	-	-	-	-	GU12356400	4
50	Plug	-	-	-	-	-	GU93180105	2




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Connector 15 vie	-	-	-	-	GU14756251	1	
2	Rubber fuse box	-	-	-	-	GU17743000	1	
3	Screw	-	-	-	-	GU98202530	2	
4	Washer	-	-	-	-	GU95000205	4	
5	Nut	-	-	-	-	GU92630105	4	
6	Horn	-	-	-	-	GU14743700	1	
	Bass horn	-	-	-	-	GU14743701	1	
7	Screw M8X25	-	-	-	-	GU98054425	1	
8	Washer	-	-	-	-	GU95000208	1	
9	Washer	-	-	-	-	GU95000206	2	
10	Spring washer	-	-	-	-	GU95021108	3	
11	Nut M8X1,25	-	-	-	-	GU92602208	1	
12	Electrical system	-	-	-	-	GU14747155	1	
13	Connector 15 vie	-	-	-	-	GU14756151	1	
14	Connector	-	-	-	-	GU14759050	1	
15	Dashboard cable	-	-	-	-	GU14747255	1	
16	Connector 12 vie	-	-	-	-	GU14758950	1	
17	Hose clamp 3,6x20,6	-	-	-	-	GU14609650	10	
18	Male connector	-	-	-	-	GU93400863	2	
19	Instrument wiring harness	-	-	-	-	GU14748155	1	
20	Wire	-	-	-	-	GU18759550	1	
21	RH front turn indicator	-	-	-	-	GU17750661	1	
22	LH front turn indicator	-	-	-	-	GU17750662	1	
23	Lamp 12V-10W	-	-	-	-	GU93450129	4	
24	Cap	-	-	-	-	GU17751160	2	
25	Horn cable	-	-	-	-	GU14748000	1	
26	Spacer	-	-	-	-	GU91180404	4	
27	RH gasket	-	-	-	-	GU17750761	1	
28	LH gasket	-	-	-	-	GU17750861	1	
29	Screw	-	-	-	-	GU98202440	4	
30	Washer	-	-	-	-	GU95007204	8	
31	Nut	-	-	-	-	GU92601004	4	
32	Cover	-	-	-	-	GU17743100	1	

33	Fuse 16A	-	-	-	-	-	GU17742550	6
34	Number plate bracket	-	-	-	-	-	GU17753560	1
35	Nut M6x1	-	-	-	-	-	GU92602406	2
36	Front turn indicator	-	-	-	-	-	GU28750645	2
38	Rear turn signal lens	-	-	-	-	-	GU14753755	2
39	Hose clamp 2,4x92	-	-	-	-	-	GU49609601	2
40	Plate holder support	-	-	-	-	-	GU17436860	1
41	Flasher unit	-	-	-	-	-	GU17750520	2
42	Block	-	-	-	-	-	GU17751200	1
43	Fuse cable	-	-	-	-	-	GU17757240	1
44	Wiring	-	-	-	-	-	GU18720150	1
47	Starter relay	-	-	-	-	-	GU19732500	1
48	Screw	-	-	-	-	-	GU98054220	1





Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Front master cilinder	-	-	-	-	GU28660178	1	
2	Front brake lever	-	-	-	-	GU14605650	1	
3	Tank cap	-	-	-	-	GU17661052	1	
4	Hose clamp	-	-	-	-	GU17658460	1	
5	Lever overhaul kit	-	-	-	-	GU17659450	1	
6	Brake calipers decal	-	-	-	-	GU14654900	1	
7	Cap	-	-	-	-	GU14663850	1	
8	Pipe	-	-	-	-	GU17657161	1	
9	Ring	-	-	-	-	GU17658260	1	
10	Gasket	-	-	-	-	GU25656102	3	
	Gasket	-	-	-	-	GU25656100	3	
11	Brake light switch	-	-	-	-	GU14657050	1	
12	RH front brake caliper	-	-	-	-	GU28653001	1	
13	Washer 10,2x18x2	-	-	-	-	GU95004210	2	
14	Clearance washer 0,8 mm	-	-	-	-	GU95100333	4	
	Clearance washer 0,5 mm	-	-	-	-	GU95100332	4	
15	Screw	-	-	-	-	GU98054530	2	
16	Pads (pair) Frendo 222	-	-	-	-	GU28654601	2	
17	Brake caliper cover	-	-	-	-	GU17654760	1	
18	Rear pump rev. kit	-	-	-	-	GU17659352	1	
19	Bleeder+cap	-	-	-	-	GU17659260	1	
20	Pins+Caliper springs	-	-	-	-	GU14659100	1	
21	Brake caliper rev. kit	-	-	-	-	GU14659000	1	
22	Pump cover	-	-	-	-	GU17661152	1	



Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Brake lever	-	-	-	-	GU17677050	1	
2	Bush	-	-	-	-	GU17252050	1	
3	Rubber spacer	-	-	-	-	GU14251001	1	
4	Nut	-	-	-	-	GU92701120	1	
5	Washer	-	-	-	-	GU17252750	1	
6	Screw	-	-	-	-	GU30252360	1	
7	Nut	-	-	-	-	GU92602206	3	
8	Hex screw M6X20	-	-	-	-	GU98054320	1	
9	Split pin	-	-	-	-	GU95500222	2	
10	Washer	-	-	-	-	GU95129110	1	
11	Pin	-	-	-	-	GU95770265	1	
12	Brake m.cyl. rod assy	-	-	-	-	GU17675051	1	
13	Tie rod	-	-	-	-	GU17675151	1	
14	Fork	-	-	-	-	GU95740175	1	
15	Nut	-	-	-	-	GU92690073	1	
16	Washer 7,5x13x1	-	-	-	-	GU95100173	1	
17	Spring washer	-	-	-	-	GU95129130	1	
18	Pads kit	-	-	-	-	GU14659450	1	
19	Washer	-	-	-	-	GU95001206	2	
20	Screw	-	-	-	-	GU98260416	1	
21	Pump control lever	-	-	-	-	GU17667551	1	
22	Spring	-	-	-	-	GU17667651	1	
23	Screw M8X40	-	-	-	-	GU98620440	1	
24	Spring washer	-	-	-	-	GU95021108	2	
25	Nut M8X1,25	-	-	-	-	GU92602208	2	
26	Rear master cylinder	-	-	-	-	GU29667000	1	
27	Pump cover	-	-	-	-	GU18667450	1	
28	Rear divider	-	-	-	-	GU18658560	1	
29	Oil pipe screw *	-	-	-	-	GU95990028	2	
30	Gasket	-	-	-	-	GU25656100	7	
31	Pressure valve	-	-	-	-	GU18668560	1	
32	Switch	-	-	-	-	GU63657000	1	
33	Notched washer	-	-	-	-	GU95021106	3	


34	Pipe	-	-	-	-	-	GU17657550	1
35	Hose clamp	-	-	-	-	-	GU62436500	1
36	Snap ring	-	-	-	-	-	GU90716142	1
37	Screw	-	-	-	-	-	GU98054314	1
38	Pipe	-	-	-	-	-	GU17658650	1
39	Brake caliper d.48	-	-	-	-	-	GU18653060	1
40	Screw	-	-	-	-	-	GU98054530	4
41	Washer 10,2x18x2	-	-	-	-	-	GU95004210	4
42	Rear brake caliper bracket	-	-	-	-	-	GU18635860	1
43	Pipe	-	-	-	-	-	GU17658750	1
44	Piston ring	-	-	-	-	-	GU17659650	1
45	Hose clamp 3,6x20,6	-	-	-	-	-	GU14609650	2
46	U-bolt	-	-	-	-	-	GU93301313	1
47	Pipe guide	-	-	-	-	-	GU17659750	1
48	Ring	-	-	-	-	-	GU91551120	1
49	Screw	-	-	-	-	-	GU98074320	2
50	Ring	-	-	-	-	-	GU17658260	1
51	Brake hose	-	-	-	-	-	GU17658860	1
52	Brake caliper	-	-	-	-	-	GU28652301	1
53	Clearance washer 0,8 mm	-	-	-	-	-	GU95100333	4
	Clearance washer 0,5 mm	-	-	-	-	-	GU95100332	4
54	Cap	-	-	-	-	-	GU12735100	1
55	Pads (pair)	-	-	-	-	-	GU18654660	2
56	Pads (pair) Frendo 222	-	-	-	-	-	GU28654601	2
57	Rear brake caliper cover	-	-	-	-	-	GU14654700	1
	Brake caliper cover	-	-	-	-	-	GU17654760	1
58	Pump revision kit	-	-	-	-	-	GU17659350	1
59	Bleeder+cap	-	-	-	-	-	GU17659260	1
60	Pins+Caliper springs	-	-	-	-	-	GU14659100	1
	Pins+Caliper springs	-	-	-	-	-	GU18659150	1
61	Brake caliper rev. kit	-	-	-	-	-	GU14659000	1
62	Nut M4x0,7	-	-	-	-	-	GU92630104	1
63	Hose clamp	-	-	-	-	-	GU17658360	1
64	Cap	-	-	-	-	-	GU18669360	1

MOTO GUZZI		SP 1000 1979-1983	GU073	00	TAB N.	10		
HANDLEBAR - CONTROLS								
								
Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Handlebar	-	-	-	-	GU30600310	1	
2	Instrument support	-	-	-	-	GU17764060	1	
3	Screw	-	-	-	-	GU98054418	2	
4	Washer	-	-	-	-	GU95000208	2	
5	Speedometer	-	-	-	-	GU17761560	1	
6	Gear 90°	-	-	-	-	GU17768360	2	
7	Speedometer transmission	-	-	-	-	GU12760400	1	
8	Tachometer	-	-	-	-	GU17767260	1	
9	Gear Z=14	-	-	-	-	GU14769200	1	
10	Rev counter transmission	-	-	-	-	GU19768100	1	
11	Sheath	-	-	-	-	GU17762200	2	
12	Voltmeter	-	-	-	-	GU17784960	1	
13	Clock assy.	-	-	-	-	GU29783061001	1	
14	Rubber spacer	-	-	-	-	GU17765560	10	
15	Rubber spacer	-	-	-	-	GU17783960	6	
16	Washer	-	-	-	-	GU95100060	5	
17	Cover	-	-	-	-	GU17766260	1	
18	RH indicators	-	-	-	-	GU14765855	1	
19	LH indicators	-	-	-	-	GU14765955	1	
20	Lampholder	-	-	-	-	GU14768655	8	
21	Lamp 12V-1,2W	-	-	-	-	GU93450140	8	
22	LH lights selector	-	-	-	-	GU18738062	1	
23	Throttle	-	-	-	-	GU14603455	1	
24	RH hand grip	-	-	-	-	GU14603500	1	
25	LH hand grip	-	-	-	-	GU14603000	1	
26	Clutch lever control	-	-	-	-	GU19605501	1	
28	Hex socket screw M6X18	-	-	-	-	GU98622318	1	
29	Switch	-	-	-	-	GU17745760	1	
30	Plate	-	-	-	-	GU17746360	1	
31	Gear Z5/11	-	-	-	-	GU14762510	1	
32	Pinion Z5	-	-	-	-	GU12763300	1	
33	Chain ring Z11	-	-	-	-	GU14766110	1	
34	Nut	-	-	-	-	GU92630105	2	
35	Hose clamp 2,4x92	-	-	-	-	GU49609601	4	
36	Lampholder	-	-	-	-	GU14768650	4	
37	Lamp 12v-3w	-	-	-	-	GU93450120	4	
38	Plate	-	-	-	-	GU14765355	1	
39	Washer	-	-	-	-	GU95001206	2	
40	Self-tap screw	-	-	-	-	GU99200513	2	




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Spring washer	-	-	-	-	GU95021108	2	
2	Nut M8X1,25	-	-	-	-	GU92602208	2	
3	Lateral stand	-	-	-	-	GU17432060	1	
4	Washer	-	-	-	-	GU95004208	7	
5	Pin	-	-	-	-	GU99105129	1	
6	Spring	-	-	-	-	GU17434060	2	
7	Plate	-	-	-	-	GU14418200	1	
8	Hex screw M8X16	-	-	-	-	GU98054416	7	
9	Central stand	-	-	-	-	GU174303621	1	
10	LH plate	-	-	-	-	GU14433200	1	
11	RH plate	-	-	-	-	GU14432900	1	
12	Lateral stand spring	-	-	-	-	GU12434001	2	
13	LH bush	-	-	-	-	GU14433500	2	
14	Screw	-	-	-	-	GU98052545	2	
15	Washer 10,2x18x2	-	-	-	-	GU95004210	2	
16	Spring washer 19x34x1,5	-	-	-	-	GU14433400	2	
17	Nut	-	-	-	-	GU92630108	1	
18	Nut M10X1,5	-	-	-	-	GU92630110	2	
19	RH cradle arm	-	-	-	-	GU17420350	1	
20	LH cradle arm	-	-	-	-	GU174221501	1	
21	Rubber spacer	-	-	-	-	GU14423800	1	
22	RH footrest	-	-	-	-	GU17443660	1	
23	LH footrest	-	-	-	-	GU17446050	1	
24	Plate	-	-	-	-	GU17444250	2	
25	Footrest rubber	-	-	-	-	GU14443200	4	
26	Nut	-	-	-	-	GU92601206	2	
27	Screw	-	-	-	-	GU98052325	3	
28	Footrest	-	-	-	-	GU144413501	2	
29	Plate	-	-	-	-	GU17432761	1	
30	Screw	-	-	-	-	GU98613635	3	
31	Rubber pedal	-	-	-	-	GU13432640	1	
32	Low nut M12x1,25	-	-	-	-	GU92602512	1	
33	Nut	-	-	-	-	GU92602312	6	

34	Notched washer	-	-	-	-	-	GU95022112	4
35	Tie rod	-	-	-	-	-	GU14429505	1
36	Pin M12x250	-	-	-	-	-	GU03429600	1
37	LH outer spacer	-	-	-	-	-	GU14429900	2
38	Spacer	-	-	-	-	-	GU14429800	2
39	Washer	-	-	-	-	-	GU95000213	4
40	Screw	-	-	-	-	-	GU98613630	1





Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Front wheel	-	-	-	-	GU17610360	1	
2	Nut M16X1,5	-	-	-	-	GU92602516	1	
3	Washer 17X27X2	-	-	-	-	GU95004217	1	
4	Spacer	-	-	-	-	GU17616360	1	
5	Nut	-	-	-	-	GU92630508	12	
6	Screw	-	-	-	-	GU98052499	6	
7	Front brake disc	-	-	-	-	GU28613345	2	
8	Bearing	-	-	-	-	GU92204221	2	
9	Spacer	-	-	-	-	GU14634051	1	
10	Front wheel spindle	-	-	-	-	GU17614160	1	
11	Counterweight	-	-	-	-	GU14616150	2	
13	Rear wheel	-	-	-	-	GU14630650	1	
14	Hub	-	-	-	-	GU14632250	1	
15	Nut M6X1,5	-	-	-	-	GU92602316	1	
16	Washer	-	-	-	-	GU14634400	1	
17	Spacer	-	-	-	-	GU17634150	1	
18	Pin	-	-	-	-	GU17633360	1	
19	Screw	-	-	-	-	GU98052445	6	
20	Rear brake disc	-	-	-	-	GU14635750	1	
21	Hex screw M6X20	-	-	-	-	GU98054320	3	
22	Notched washer	-	-	-	-	GU95021106	3	
23	Flange	-	-	-	-	GU14335650	1	
24	Ring	-	-	-	-	GU14335350	1	
25	Flexible coupling disc	-	-	-	-	GU14335203	1	
26	Rubber cush drive hub	-	-	-	-	GU01336800	12	
27	O-ring	-	-	-	-	GU90706490	1	
28	Circlip	-	-	-	-	GU90271055	1	
29	Bearing internal spacer	-	-	-	-	GU14634050	1	
30	Ball bearing 20X47X14	-	-	-	-	GU92204220	2	
31	Rear wheel	-	-	-	-	GU17630261	1	

MOTO GUZZI		SP 1000 1979-1983	GU073	00	TAB N.	13		
FRAME								
Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Frame	-	-	-	-	GU17400150	1	
2	Steering lock	-	-	-	-	GU28782550	1	
3	Plug	-	-	-	-	GU93180080	4	
4	Screw	-	-	-	-	GU98074425	2	
5	Washer	-	-	-	-	GU95001208	2	
6	Spacer	-	-	-	-	GU91180810	2	
7	Rubber spacer	-	-	-	-	GU14103400	2	
8	Drift	-	-	-	-	GU14107100	1	
9	Rubber spacer	-	-	-	-	GU14109000	2	
10	Hose clamp 3,6x20,6	-	-	-	-	GU14609650	3	
11	Plate	-	-	-	-	GU14749755	1	
12	Plate	-	-	-	-	GU17750400	1	
13	Washer	-	-	-	-	GU95000206	3	
14	Tool kit box	-	-	-	-	GU17479650	1	
15	Clamp	-	-	-	-	GU17479750	1	
16	Nut	-	-	-	-	GU92601206	2	
17	Screw	-	-	-	-	GU98613630	2	
18	Nut	-	-	-	-	GU92630105	2	
19	Nut	-	-	-	-	GU92602312	2	
20	Notched washer	-	-	-	-	GU95022112	2	
21	Hex screw M6X20	-	-	-	-	GU98054320	2	
22	Washer	-	-	-	-	GU95000206	7	
23	Drift	-	-	-	-	GU14103800	4	
24	Notched washer	-	-	-	-	GU95021106	6	
25	RH plate	-	-	-	-	GU174248501	1	
26	LH plate	-	-	-	-	GU17424050	1	
27	Rubber spacer	-	-	-	-	GU39461600	4	
28	Screw	-	-	-	-	GU98052325	2	
29	Screw	-	-	-	-	GU98054220	2	
30	U-bolt	-	-	-	-	GU93301313	1	
31	Nut M6x1	-	-	-	-	GU92630106	4	
32	LH pin	-	-	-	-	GU17478550	2	
33	Plate	-	-	-	-	GU17709950	1	
34	Plate	-	-	-	-	GU14716750	1	
35	Plate	-	-	-	-	GU147040501	1	
36	Hex screw M6X16	-	-	-	-	GU98054316	1	
37	Washer 5,3x10x0,5	-	-	-	-	GU95100121	4	




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Drive shaft	-	-	-	-	GU18064204	1	
2	Plug	-	-	-	-	GU12065400	1	
3	Transmission key	-	-	-	-	GU91702355	1	
4	Pinion	-	-	-	-	GU14072001	1	
5	Safety washer	-	-	-	-	GU95028025	1	
6	Ring nut	-	-	-	-	GU93601026	1	
7	Flywheel	-	-	-	-	GU17067050	1	
8	Washer 8,4X13X0,8	-	-	-	-	GU14615901	6	
9	Screw M8X25	-	-	-	-	GU12067701	6	
10	Chain ring	-	-	-	-	GU17067900	1	
11	Washer 8,4X13X0,8	-	-	-	-	GU14615901	8	
12	Hex screw M8X20	-	-	-	-	GU98054420	8	
13	Connecting rod	-	-	-	-	GU14061550	2	
14	Bush	-	-	-	-	GU91112128	2	
15	Self-locking nut	-	-	-	-	GU92731090	4	
16	Screw	-	-	-	-	GU30062260	4	
17	Bearing half-shell 0,762 mm	-	-	-	MIN	GU30062003	4	
	Bearing half-shell	-	-	-	std	GU30062000	4	
	Bearing half-shell 0,254 mm	-	-	-	MIN	GU30062001	4	
	Bearing half-shell 0,508 mm	-	-	-	MIN	GU30062002	4	
18	Piston	-	-	-	std	GU18060450	2	
19	Piston ring	-	-	-	std	GU18060750	2	
20	Piston ring	-	-	-	std	GU18060950	2	
21	Oil scraper ring	-	-	-	std	GU14061060	2	
22	Piston pin	-	-	-	-	GU13061260	2	
23	Stop ring	-	-	-	-	GU27061385	4	
25	Piston rings set	-	-	-	std	GU17060660	2	
26	Rocker arm rod	-	-	-	-	GU37045006	4	
27	Tappet	-	-	-	-	GU17045860	4	
28	Camshaft	-	-	-	-	GU14053301	1	
29	Flange	-	-	-	-	GU12054000	1	
30	Hex screw M6X20	-	-	-	-	GU98054320	3	
31	Washer 6,5x11x2	-	-	-	-	GU95120065	3	

32	Timing system gear	-	-	-	-	-	GU13054502	1
33	Pin	-	-	-	-	-	GU14234600	1
34	Spring washer 19x34x1,5	-	-	-	-	-	GU14433400	1
35	Nut M18X1,5	-	-	-	-	-	GU92602518	1
36	Chain	-	-	-	-	-	GU28058060	1
37	Chain tensioner	-	-	-	-	-	GU30057810	1
38	Spacer	-	-	-	-	-	GU91180915	2
39	Screw	-	-	-	-	-	GU98054440	2
40	Spring washer 8x15x0,3	-	-	-	-	-	GU61270300	2

	SP 1000 1979-1983	GU073	00	TAB N.	15			
	INTAKE-EXHAUST							
								
Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.



1	Intake pipe	-	-	-	-	GU17114350	1	
2	Pipe	-	-	-	-	GU17114650	1	
3	Breather	-	-	-	-	GU17155751	1	
4	Clamp	-	-	-	-	GU17114553	2	
5	Spring	-	-	-	-	GU17667650	2	
6	Ring	-	-	-	-	GU17113450	1	
7	Air filter	-	-	-	-	GU17113651	1	
8	Filter cover	-	-	-	-	GU17114050	1	
9	Plate	-	-	-	-	GU17114150	1	
10	Washer 5,25x14x1,5	-	-	-	-	GU95100059	1	
11	Nut	-	-	-	-	GU92602205	1	
12	Screw	-	-	-	-	GU98054314	1	
13	Notched washer	-	-	-	-	GU95021106	1	
14	Nut	-	-	-	-	GU92602206	1	
15	Sparkplug cap	-	-	-	-	GU17154850	1	
16	Sparkplug cap	-	-	-	-	GU17154950	1	
17	Hose clamp	-	-	-	-	GU93305017	5	
18	Hose clamp	-	-	-	-	GU12157800	1	
19	Breather pipe	-	-	-	-	GU17159650	2	
20	Screw	-	-	-	-	GU95990037	2	
21	Gasket 8,25x15x1	-	-	-	-	GU12154200	4	
22	Breather pipe	-	-	-	-	GU95985532	1	
23	Hose clamp D9	-	-	-	-	GU61108500	2	
24	Plate	-	-	-	-	GU14115401	1	
25	Breather pipe	-	-	-	-	GU01007200	1	
26	Gasket	-	-	-	-	GU12007600	1	
27	Screw	-	-	-	-	GU98054318	2	
28	Washer 6,5x11x2	-	-	-	-	GU95120065	2	
29	Breather	-	-	-	-	GU17006250	1	
30	Hose clamp	-	-	-	-	GU12006500	1	
31	Screw	-	-	-	-	GU12006600	1	
32	Gasket 12,25	-	-	-	-	GU12006400	2	
33	Pipe	-	-	-	-	GU14153601	1	

34	Screw	-	-	-	-	-	GU95990037	3
35	Gasket 8,25x15x1	-	-	-	-	-	GU12154200	6
36	RH exhaust pipe	-	-	-	-	-	GU14120901	1
37	LH exhaust pipe	-	-	-	-	-	GU14120906	1
38	Gasket	-	-	-	-	-	GU90718370	2
39	Spacer	-	-	-	-	-	GU14121200	2
40	Flange	-	-	-	-	-	GU17121061	2
41	Washer 8,4X13X0,8	-	-	-	-	-	GU14615901	4
42	Nut M8X1,25	-	-	-	-	-	GU92602208	6
43	Expansion chamber	-	-	-	-	-	GU17123962	1
44	RH silencer S17	-	-	-	-	-	GU17123062	1
45	LH silencer S17	-	-	-	-	-	GU17122962	1
46	Hose clamp	-	-	-	-	-	GU14126900	2
47	Hose clamp	-	-	-	-	-	GU14123400	2
48	Hex screw M8X20	-	-	-	-	-	GU98054420	2
49	Spring washer	-	-	-	-	-	GU95021108	2
50	Nut M8X1,25	-	-	-	-	-	GU92602208	2
51	Rubber spacer 8x15	-	-	-	-	-	GU91551081	1
52	RH clamp	-	-	-	-	-	GU17128662	1
53	LH clamp	-	-	-	-	-	GU17128762	1
54	Spring washer	-	-	-	-	-	GU95021108	4
55	Nut M8X1,25	-	-	-	-	-	GU92602208	4
56	Oil breather valve	-	-	-	-	-	GU28150560	1
57	Hose clamp 3,6x20,6	-	-	-	-	-	GU14609650	2




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Ring nut	-	-	-	-	GU93601022	1	
2	Washer 22x20x3,9	-	-	-	-	GU95028022	1	
3	Clutch gear	-	-	-	-	GU29999350	1	
4	O-ring 23,52x1,78	-	-	-	-	GU90706235	1	
5	Clutch shaft	-	-	-	-	GU14210702	1	
6	O-ring 20,24X2,62	-	-	-	-	GU90706203	2	
7	Oil-spreading washer 25,1x36x0,5	-	-	-	-	GU14218401	1	
8	Gear Z=17	-	-	-	-	GU14211110	1	
9	Hose	-	-	-	-	GU14211201	1	
10	Belleville spring	-	-	-	-	GU13211500	1	
11	Disc	-	-	-	-	GU14211600	1	
12	Half ring	-	-	-	-	GU12211700	2	
13	Spacer	-	-	-	-	GU14219401	1	
14	Primary gear shaft	-	-	-	-	GU14210513	1	
15	Thrust washer sp.2,1	-	-	-	-	GU18211051	1	
	Thrust washer sp.2,2	-	-	-	-	GU18211052	1	
	Thrust washer sp.2,4	-	-	-	-	GU18211054	1	
	Thrust washer sp.2	-	-	-	-	GU18211050	1	
16	Roller bearing	-	-	-	-	GU92258525	1	
17	Gear 5a Z=28	-	-	-	-	GU14212013	1	
18	Roller	-	-	-	-	GU92296750	1	
19	Spring	-	-	-	-	GU94321051	1	
20	Roller cage 30x35x13	-	-	-	-	GU92251030	4	
21	Bush 5a AP	-	-	-	-	GU14212210	1	
22	Sliding sleeve 5a	-	-	-	-	GU14231510	1	
23	Driven shaft	-	-	-	-	GU14213612	1	
24	Nut	-	-	-	-	GU14217410	1	
25	Shim 17,25x27x0,5	-	-	-	-	GU43083810	4	
26	Clearance washer 17,1x30	-	-	-	-	GU14215400	1	
27	Gear 4a Z=20	-	-	-	-	GU14215110	1	
28	Ring 4a	-	-	-	-	GU92259017	1	
29	Roller cage 4a A.S.	-	-	-	-	GU92251022	1	

30	Sliding sleeve 3a-4a	-	-	-	-	-	GU14231012	1
31	Hose	-	-	-	-	-	GU14232512	1
32	Washer 25x40x3	-	-	-	-	-	GU14218011	1
33	Gear 3a Z=22	-	-	-	-	-	GU14214810	1
34	Bush 1a-2a-3a AS	-	-	-	-	-	GU14213001	3
35	Gear 2a Z=25	-	-	-	-	-	GU14214510	1
36	Nut	-	-	-	-	-	GU14219310	1
37	Ball	-	-	-	-	-	GU92295702	1
38	Washer 22,1x32x2	-	-	-	-	-	GU14217300	1
39	Gear 5a AS Z=21	-	-	-	-	-	GU14215213	1
40	Gear 1a Z=28	-	-	-	-	-	GU14214210	1
41	Sliding sleeve 1a-2a	-	-	-	-	-	GU14230711	1
42	Shift cam	-	-	-	-	-	GU14234405	1
43	Washer 8,2x28x1	-	-	-	-	-	GU14235500	1
44	Shim 0,6 mm	-	-	-	-	-	GU55235000	3
	Shim 1,2 mm	-	-	-	-	-	GU55235003	3
	Shim 0,8 mm	-	-	-	-	-	GU55235001	3
	Shim 1 mm	-	-	-	-	-	GU55235002	3
45	Rod	-	-	-	-	-	GU14234300	1
46	Pin	-	-	-	-	-	GU14234600	4
47	Rod	-	-	-	-	-	GU14232400	1
48	Fork 1a-2a-3a-4a	-	-	-	-	-	GU14230501	2
49	Fork 5a	-	-	-	-	-	GU14231201	1
50	Preselection complete	-	-	-	-	-	GU28236260	1
51	Spring	-	-	-	-	-	GU28238261	1
52	Screw	-	-	-	-	-	GU98052325	1
53	Notched washer	-	-	-	-	-	GU95021106	1
54	Lever	-	-	-	-	-	GU18258201	1
55	Split pin	-	-	-	-	-	GU95500222	1
56	Nut M6x1	-	-	-	-	-	GU92630106	1
57	Washer	-	-	-	-	-	GU95129110	1
58	Pin	-	-	-	-	-	GU95770265	1
59	Fork	-	-	-	-	-	GU12626800	1
60	Nut	-	-	-	-	-	GU92602206	1
61	Fork	-	-	-	-	-	GU18257801	1
62	Rubber spacer	-	-	-	-	-	GU14251001	1
63	Gear lever	-	-	-	-	-	GU17250950	1
64	Bush	-	-	-	-	-	GU17252050	1
65	Nut	-	-	-	-	-	GU92701120	1
66	Washer	-	-	-	-	-	GU17252750	1
67	Screw	-	-	-	-	-	GU30252360	1
68	O-ring 21,95x1,78	-	-	-	-	-	GU90706219	1
69	Ball joint	-	-	-	-	-	GU18258101	1
70	Special washer	-	-	-	-	-	GU61013800	1

	SP 1000 1979-1983	GU073	00	TAB N.	17			
	CARBURETTORS							
								
Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.


1	Gasket	-	-	-	-	GU14115500	4	
2	RH intake manifold	-	-	-	-	GU14115002	1	
3	LH intake manifold	-	-	-	-	GU14115003	1	
4	Screw	-	-	-	-	GU98326009	2	
5	Washer 6,25x10x1,5	-	-	-	-	GU95100116	2	
6	Screw M8X35	-	-	-	-	GU98620435	6	
7	Washer	-	-	-	-	GU90716083	6	
8	Washer	-	-	-	-	GU95004208	6	
9	Plate	-	-	-	-	GU14115401	2	
10	Rubber spacer 8x15	-	-	-	-	GU91551081	2	
11	Carburettor RH	-	-	-	-	GU18112650	1	
12	Carburettor LH	-	-	-	-	GU18112651	1	
13	Throttle cable	-	-	-	-	GU17117561	2	
14	Starter lever	-	-	-	-	GU17133151	1	
15	LH choke cable	-	-	-	-	GU17133550	1	
16	LH choke cable	-	-	-	-	GU17134060	1	
17	Air intake pipe	-	-	-	-	GU17114450	2	
18	Screw	-	-	-	-	GU98054210	1	
19	Notched washer	-	-	-	-	GU95021105	1	
20	Fuel pipe	-	-	-	-	GU17106550	1	
21	Hose clamp	-	-	-	-	GU61108400	4	
22	Carburettor gasket kit	-	-	-	-	GU17939950	1	
24	Wire tensioner screw	-	-	-	-	GU12937200	2	
25	Nut	-	-	-	-	GU12937300	2	
26	Screw	-	-	-	-	GU13937900	1	
27	Starter device cover	-	-	-	-	GU17937450	1	
29	Spring	-	-	-	-	GU13937600	1	
30	Starter valve	-	-	-	-	GU13937800	1	
31	Adj.min.eng.speed screw	-	-	-	-	GU13936200	1	
32	Spring	-	-	-	-	GU13936300	1	
33	Gas valve adjuster screw	-	-	-	-	GU13936600	1	
34	Spring	-	-	-	-	GU13936700	1	
35	Screw	-	-	-	-	GU13932800	2	

36	Washer	-	-	-	-	-	GU13932900	2
37	Gas valve cover	-	-	-	-	-	GU13935000	1
39	Spring	-	-	-	-	-	GU13937100	1
40	Conical pin clip	-	-	-	-	-	GU55938585	1
41	Gas valve	-	-	-	-	-	GU14937501	1
42	Conical pin	-	-	-	-	-	GU14937701	1
43	Plate	-	-	-	-	-	GU14936800	1
44	Hose clamp	-	-	-	-	-	GU14938700	1
45	Insulating reduction	-	-	-	-	-	GU14938900	1
46	Screw	-	-	-	-	-	GU14938600	1
47	Fuel pump	-	-	-	-	-	GU17938900	1
48	Piston	-	-	-	-	-	GU17939000	1
49	Valve	-	-	-	-	-	GU17939100	1
50	Valve holder	-	-	-	-	-	GU17939200	1
51	Spring	-	-	-	-	-	GU17939300	1
52	Jetholder	-	-	-	-	-	GU17939400	1
53	Main jet 125	-	-	-	-	-	GU18935750	1
55	Plug	-	-	-	-	-	GU13933700	1
56	Starter jet	-	-	-	-	-	GU13936000	1
58	Needle valve	-	-	-	-	-	GU13935500	1
59	Idle jet 50	-	-	-	-	-	GU66935910	1
60	Jet Needle	-	-	-	-	-	GU13934800	1
61	Fuel pipe union cap	-	-	-	-	-	GU13934600	1
63	Cap fixing screw	-	-	-	-	-	GU10934900	1
65	Float	-	-	-	-	-	GU14933000	1
66	Float pin	-	-	-	-	-	GU13933100	1
68	Float chamber	-	-	-	-	-	GU13934400	1
69	Fuel pump cpl.	-	-	-	-	-	GU14938800	1




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Crankcase	-	-	-	-	GU18000750	1	
2	Disc	-	-	-	-	GU12003900	1	
3	Stud bolt M8X66	-	-	-	-	GU96508066	4	
4	Stud bolt M8x75	-	-	-	-	GU96508075	2	
5	Washer	-	-	-	-	GU95004208	5	
6	Nut M8X1,25	-	-	-	-	GU92602208	6	
7	Coupling bush	-	-	-	-	GU12018900	2	
8	Pin	-	-	-	-	GU95512081	2	
9	Complete flange	-	-	-	-	GU14011900	1	
10	Pin	-	-	-	-	GU12012200	1	
11	Screw M8X25	-	-	-	-	GU98054425	14	
12	Spring washer 8x15x0,3	-	-	-	-	GU61270300	14	
13	Flange	-	-	-	-	GU18001150	1	
14	Screw	-	-	-	-	GU98310630	4	
15	Timing system cover	-	-	-	-	GU14001400	1	
16	Cover gasket	-	-	-	-	GU12001200	1	
17	Gasket ring 28x38x7	-	-	-	-	GU90402840	1	
18	Hex socket screw M6X25	-	-	-	-	GU98622325	22	
19	Screw M6X35	-	-	-	-	GU98620335	6	
20	Cover	-	-	-	-	GU18001650	1	
21	Sump gasket	-	-	-	-	GU14003600	1	
22	Motor oil cup	-	-	-	-	GU03003501001	1	
23	Oil filter union 61 mm	-	-	-	-	GU14003800	1	
24	Oil unload plug	-	-	-	-	GU12003702	1	
25	Gasket 20,1x28x2	-	-	-	-	GU95100709	2	
26	Screw M6X60	-	-	-	-	GU98620355	4	
27	Washer 6,15x11x0,8	-	-	-	-	GU95008206	18	
28	Oil plug	-	-	-	-	GU17004960	1	
29	Gasket	-	-	-	-	GU12011800	1	
30	Flange min.0,2 mm	-	-	-	-	GU12011401	1	
	Flange min.0,4 mm	-	-	-	-	GU12011402	1	
	Complete flange	-	-	-	-	GU12011400	1	
	Flange min.0,6 mm	-	-	-	-	GU12011403	1	
31	Pin	-	-	-	-	GU12011700	1	


32	Gasket ring	-	-	-	-	-	GU90405367	1
33	Nut	-	-	-	-	-	GU92602206	1
34	Oil pipe	-	-	-	-	-	GU170048601	1
35	Hose clamp	-	-	-	-	-	GU17005260	1
36	Screw	-	-	-	-	-	GU98054314	1
37	Washer	-	-	-	-	-	GU95000206	1
38	Engine set gasket	-	-	-	-	-	GU18999050	1
39	Engine oil seal kit	-	-	-	-	-	GU17999550	1

Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.	
									
1	RH cover	-	-	-	-	GU14023650	1		
2	LH cover	-	-	-	-	GU14023550	1		
3	Valve cover gasket	-	-	-	-	GU12023700	2		
4	Hex socket screw M6X25	-	-	-	-	GU98622325	16		
5	RH cylinder head	-	-	-	-	GU14022101	1		
6	LH cylinder head	-	-	-	-	GU14022201	1		
7	Exhaust valve guide	-	-	-	-	GU13036801	4		
8	Snap ring	-	-	-	-	GU90353016	4		
9	Cylinder head gasket	-	-	-	-	GU18022050	2		
10	Cylinder	-	-	-	-	GU18060151	2		
11	Cylinder base gasket	-	-	-	-	GU14020850	2		
12	O-ring 9x2	-	-	-	-	GU90706094	12		
13	Oil plug	-	-	-	-	GU12022600	2		
14	O-ring 20,24X2,62	-	-	-	-	GU90706203	2		
15	Column nut	-	-	-	-	GU13021900	2		
16	Washer 10,5X18X0,8	-	-	-	-	GU95129180	2		
17	Stud bolt	-	-	-	-	GU12021800	4		
18	Stud bolt	-	-	-	-	GU12021700	8		
19	Washer 10,5X21X1	-	-	-	-	GU14018400	10		
20	Nut M10X1,5	-	-	-	-	GU92603010	10		
21	Intake valve	-	-	-	-	GU29036050	2		
22	Exhaust valve	-	-	-	-	GU29036150	2		
23	Washer 14,2x31x1	-	-	-	-	GU13037200	4		
24	Washer 14,2x31x0,3	-	-	-	-	GU14037300	10		
25	Lower cup	-	-	-	-	GU13037000	4		
26	Outer spring	-	-	-	-	GU13037400	4		
27	Inner spring	-	-	-	-	GU13037600	4		
28	Upper cup	-	-	-	-	GU14038000	4		
29	Valve half-cone	-	-	-	-	GU12038100	8		
30	RH rocker arm assy	-	-	-	-	GU14030201	2		
31	LH rocker arm assy	-	-	-	-	GU14030401	2		
32	Bush 15x18x43	-	-	-	-	GU91111511	4		
33	Adjuster screw	-	-	-	-	GU17034050	4		


34	Nut	-	-	-	-	-	GU10034100	4
35	Spring	-	-	-	-	-	GU94322215	4
36	Washer 15,2x26x1	-	-	-	-	-	GU90118152	4
37	Rocker shaft	-	-	-	-	-	GU12031800	4
38	Screw	-	-	-	-	-	GU98054314	4
39	Washer 6,5x11x2	-	-	-	-	-	GU95120065	4
40	Rocker arm support	-	-	-	-	-	GU12034800	2
41	Support	-	-	-	-	-	GU17135650	1
42	Stud bolt	-	-	-	-	-	GU96508040	4



Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Clutch spring	-	-	-	-	GU13084100	8	
2	Disc	-	-	-	-	GU12082901	1	
3	Clutch gear	-	-	-	-	GU29999350	2	
4	Intermediate plate	-	-	-	-	GU12082300	1	
5	Cup	-	-	-	-	GU12082800	1	
6	Rod	-	-	-	-	GU14085700	1	
7	Bush	-	-	-	-	GU14085900	2	
8	Inner body	-	-	-	-	GU14086000	1	
9	Thrust bearing	-	-	-	-	GU12087001	1	
10	Outer body	-	-	-	-	GU14086100	1	
11	O-ring 17,13x2,62	-	-	-	-	GU90706170	1	
12	Clutch release shaft	-	-	-	-	GU14090202	1	
13	Lever return spring	-	-	-	-	GU94321105	1	
14	Adjuster screw	-	-	-	-	GU14090400	1	
15	Nut M8X1	-	-	-	-	GU92602508	1	
16	Pin 7x39	-	-	-	-	GU95780271	1	
17	Split pin	-	-	-	-	GU95500222	1	
18	Clutch cable	-	-	-	-	GU14093051	1	
19	Cap	-	-	-	-	GU17093850	1	



Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Oil pump gear	-	-	-	-	GU30147700	1	
2	Driven gear	-	-	-	-	GU13148400	1	
3	Drive gear	-	-	-	-	GU13147800	1	
4	Transmission key	-	-	-	-	GU13148300	1	
5	Roller bearing 10x22x20	-	-	-	-	GU92252210	1	
6	Oil pump gear	-	-	-	-	GU13147701	1	
7	Nut	-	-	-	-	GU92602308	1	
8	Spring washer	-	-	-	-	GU95120085	1	
9	Screw M8X30	-	-	-	-	GU98622430	4	
10	Oil filter	-	-	-	-	GU14152200	1	
11	Hex screw M6X16	-	-	-	-	GU98054316	1	
12	Plate	-	-	-	-	GU95187006	1	
13	Oil filter 61 mm	-	-	-	-	GU14153000	1	
14	Oil valve cpl.	-	-	-	-	GU03158200	1	
15	Valve body	-	-	-	-	GU10158701	1	
16	Piston	-	-	-	-	GU12150900	1	
17	Valve spring	-	-	-	-	GU94321072	1	
18	Bottom	-	-	-	-	GU12150700	1	
19	Plug	-	-	-	-	GU12159000	1	
20	Washer 14,5X20X1	-	-	-	-	GU95100523	1	
21	Cup	-	-	-	-	GU14158800	1	
22	Pressure sensor	-	-	-	-	GU17768750	1	
23	Gasket 12,25	-	-	-	-	GU12006400	1	
24	Cap	-	-	-	-	GU12717600	1	



Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Gearbox, blank	-	-	-	-	GU14200211	1	
2	Gasket ring 35x47x7/6,5	-	-	-	-	GU90403548	1	
3	Roller bearing 17x35x15	-	-	-	-	GU92256218	2	
4	Plate	-	-	-	-	GU14213803	2	
5	Hex socket screw M6X16	-	-	-	-	GU98622316	6	
6	Washer 6,4x10x0,7	-	-	-	-	GU14217901	6	
7	Ball bearing AF/AS 25x52	-	-	-	-	GU92218424	2	
8	Roller bearing AS 17x47x14	-	-	-	-	GU92234717	1	
9	Pin	-	-	-	-	GU95512081	2	
10	Gasket	-	-	-	-	GU14201110	1	
11	Box cover, blank	-	-	-	-	GU18200802	1	
12	O-ring 13,95x2,92	-	-	-	-	GU90706140	1	
13	Ball bearing AP 17x47x14	-	-	-	-	GU92201417	1	
14	Screw	-	-	-	-	GU14237800	1	
15	Low nut M12x1,25	-	-	-	-	GU92602512	1	
16	Hex socket screw M6X25	-	-	-	-	GU98622325	10	
17	Screw M6X35	-	-	-	-	GU98620335	1	
18	Neutral indicator switch	-	-	-	-	GU12207200	1	
19	Gasket	-	-	-	-	GU12207700	1	
20	Washer	-	-	-	-	GU95000206	2	
21	Hex screw M6X16	-	-	-	-	GU98054316	2	
22	Plug	-	-	-	-	GU93180220	1	
23	Oil unload plug	-	-	-	-	GU12003702	1	
24	Gasket 20,1x28x2	-	-	-	-	GU95100709	1	
25	Plug	-	-	-	-	GU95980610	2	
26	Gasket	-	-	-	-	GU10528900	3	
27	Oil hose union	-	-	-	-	GU12235301	1	
28	Rubber pipe 12,5X7,8 5/16"	-	-	-	-	GU00823956080	1	
29	Lever return spring	-	-	-	-	GU94321067	1	
30	Pawl	-	-	-	-	GU55234700	1	
31	Gasket ring 35x47x7	-	-	-	-	GU90403547	1	