




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Windscreen cpl.	-	-	-	-	GU31575162	1	
2	Screw	-	-	-	-	GU98270620	4	
3	Washer	-	-	-	-	GU03530543	4	
4	Silent-block	-	-	-	-	GU03530546	4	
5	Spacer	-	-	-	-	GU03530545	4	
6	Washer	-	-	-	-	GU03530544	8	
7	Screw	-	-	-	-	GU98622420	2	
8	Nut M8X1,25	-	-	-	-	GU92602208	4	
9	Screw M8X45	-	-	-	-	GU98622445	2	
10	Screw	-	-	-	-	GU98620545	2	
11	Front bumper	-	-	-	-	GU31459866	1	
13	Screw M10X40	-	-	-	-	GU98620540	2	
14	Screw	-	-	-	-	GU98622420	2	
15	Rubber spacer	-	-	-	-	GU93180216	2	




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Battery 12V-24Ah	-	-	-	-	GU28704552	1	
2	Battery holder	-	-	-	-	GU28707050	1	
3	Clamp	-	-	-	-	GU19704800	1	
4	Accumulator fixing wedge	-	-	-	-	GU31705360	1	
5	Cap	-	-	-	-	GU19707100	2	
6	Wire	-	-	-	-	GU19748000	1	
7	Ground-battery lead	-	-	-	-	GU19748400	1	
8	Generator SAPRISA	W	-	-	SA	GU28712400	1	
9	Voltage regulator SAPRISA	W	-	-	SA	GU28703800	1	
10	Connector SAPRISA	W	-	-	-	GU28712500	1	
11	Notched washer	-	-	-	-	GU95021105	3	
12	Screw	-	-	-	-	GU98620250	1	
13	Screw	-	-	-	-	GU28712459	3	
14	Hex socket screw M6X16	-	-	-	-	GU98622316	2	
15	Special washer	-	-	-	-	GU61013800	2	
16	Captive nut	-	-	-	-	GU92660601	2	
17	Support plate	-	-	-	-	GU29704060	1	
18	Screw	-	-	-	-	GU98622416	2	
19	Washer	-	-	-	-	GU95000208	2	
20	Plate	-	-	-	-	GU17451750	1	


	NEVADA CLUB 750 1998-2001	GU018	00	TAB N.	<b>03</b>
	TOP BOX				





Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Rigid top box kit	-	-	-	-	GU31487565	1	
2	Top box 40 L	-	-	-	-	GU31487665	1	
3	"MotoGuzzi" dec. 40 L	-	-	-	-	GU03482001	1	
4	Support plate	-	-	-	-	GU31487765	1	
5	LH clamp	-	-	-	-	GU31487866	1	
	RH clamp	-	-	-	-	GU31487865	1	
6	Screw M6X20	-	-	-	-	GU98230621	4	
7	Washer	-	-	-	-	GU95000206	4	
8	Nut M6x1	-	-	-	-	GU92630106	4	
9	Lock	-	-	-	-	GU03484001	2	
10	Lock	-	-	-	-	GU03484000	1	



Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Side cases 30 L	-	-	-	-	GU31480066	1	
2	RH suitcase 30 L	-	-	-	-	GU31482565	1	
3	LH suitcase 30 L	-	-	-	-	GU31485765	1	
4	Lock	-	-	-	-	GU03484000	2	
5	Lock	-	-	-	-	GU03484001	4	
6	"MotoGuzzi" dec. 45 L	-	-	-	-	GU03482000	2	
7	RH support	-	-	-	-	GU31485066	1	
8	LH support	-	-	-	-	GU31486566	1	
9	Screw	-	-	-	-	GU98622420	2	
10	Washer	-	-	-	-	GU95000208	4	
11	Rubber spacer	-	-	-	-	GU31488165	2	
12	Screw M8X22	-	-	-	-	GU98054422	2	
13	Nut M8X1,25	-	-	-	-	GU92602208	2	
14	Screw	-	-	-	-	GU98231045	2	
15	Washer	-	-	-	-	GU95000210	2	
16	Screw	-	-	-	-	GU98230618	4	
17	Nut M6x1	-	-	-	-	GU92630106	4	
18	Lock plate	-	-	-	00801N	GU00979726	2	



Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Leather side cases	-	-	-	-	GU31480080	1	
2	RH support	-	-	-	-	GU31486680	1	
3	LH support	-	-	-	-	GU31486780	1	
4	RH suitcase	-	-	-	-	GU03482536	1	
5	LH suitcase	-	-	-	-	GU03485736	1	
6	Screw M8X30	-	-	-	-	GU98622430	2	
7	Spacer	-	-	-	-	GU91180810	2	
9	Leather top box kit	-	-	-	-	GU31487580	1	
10	Top box	-	-	-	-	GU03487636	1	
11	Support plate	-	-	-	-	GU31487765	1	
12	LH clamp	-	-	-	-	GU31487866	1	
	RH clamp	-	-	-	-	GU31487865	1	
13	Screw M6X20	-	-	-	-	GU98230621	4	
14	Nut M6x1	-	-	-	-	GU92630106	4	
15	Washer	-	-	-	-	GU95000206	4	


		NEVADA CLUB 750 1998-2001	GU018	00	TAB N.	06		
STANDS								
								
Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.

1	RH arm polished black	-	-	-	-	GU31420383	1	
2	LH arm polished black	-	-	-	-	GU31422183	1	
3	Central stand polished black	-	-	-	-	GU31430381	1	
4	Rubber pedal	-	-	-	-	GU13432640	1	
5	Lateral stand spring	-	-	-	-	GU12434001	2	
6	Screw	-	-	-	-	GU98054530	1	
7	Spacer	-	-	-	-	GU91181114	2	
8	Spring	-	-	-	-	GU94322215	2	
9	Washer	-	-	-	-	GU95000210	3	
10	Nut M10x1,5	-	-	-	-	GU92630510	2	
11	Lateral stand	-	-	-	-	GU31432181	1	
12	Rubber spacer	-	-	-	-	GU14423800	1	
13	Pin	-	-	-	-	GU99105129	1	
14	Spring	-	-	-	-	GU17434060	2	
15	Split pin	-	-	-	-	GU95401215	2	
16	Nut	-	-	-	-	GU92602210	3	
17	Special washer	-	-	-	-	GU61013800	2	
18	RH front foot rest pipe	-	-	-	-	GU23440710	1	
19	LH front foot rest pipe	-	-	-	-	GU23441810	1	
20	Spring	-	-	-	00700N	GU03441130	2	
21	Plate	-	-	-	-	GU23441210	2	
23	Screw	-	-	-	-	GU98054314	2	
24	Rubber pedal	-	-	-	-	GU23443210	2	
25	Washer	-	-	-	-	GU95000208	2	
26	Spring washer 8x15x0,3	-	-	-	-	GU61270300	1	
27	Screw	-	-	-	-	GU98052565	2	
28	Washer 10,2x18x2	-	-	-	-	GU95004210	3	
29	Lateral stand switch	-	-	-	-	GU29759150	1	
30	Pin	-	-	-	-	GU23442210	2	
31	Bush	-	-	-	-	GU19017000	2	
32	Pin M10x250	-	-	-	-	GU53429500	1	
33	Nut M8X1	-	-	-	-	GU92602508	1	
34	Spacer	-	-	-	-	GU91180602	2	

35	Spring washer	-	-	-	-	-	GU95129130	2
36	Bush 18 mm est.	-	-	-	-	-	GU28252060	4
37	Plate	-	-	-	-	-	GU28432760	1
38	Plate	-	-	-	-	-	GU31759360	1
39	Screw	-	-	-	T2	-	GU98612110	2
	Screw	-	-	-	01101N-T3	-	GU98612118	2
40	Screw	-	-	-	-	-	GU98052535	1
41	Washer	-	-	-	01101N-T3	-	GU95007204	2
42	Nut M4x0,7	-	-	-	01101N-T3	-	GU92630104	2


Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Transmission housinggrey	-	-	-	-	GU31350380	1	
2	Clearance washer	-	-	-	-	GU19351900	1	
3	Gasket ring 35x47x7	-	-	-	-	GU90403547	1	
4	Clearance washer	-	-	-	-	GU19351100	1	
5	Roller bearing 35x50x17	-	-	-	-	GU92252235	1	
6	Oil plug	-	-	-	-	GU12022600	1	
7	O-ring 20,24X2,62	-	-	-	-	GU90706203	1	
8	Oil unload plug M10X1	-	-	-	-	GU31003766	1	
9	Gasket	-	-	-	-	GU10528900	1	
10	Breather plug	-	-	-	-	GU19206501	1	
11	Gasket	-	-	-	-	GU10528900	1	
12	Stud bolt	-	-	-	-	GU96508055	4	
13	Cover	-	-	-	-	GU27350410	1	
14	Ball bearing 70x110x13	-	-	-	-	GU92201070	1	
15	Gasket ring 75x90x8	-	-	-	-	GU90407590	1	
16	Pin	-	-	-	-	GU19351401	1	
17	Stop ring	-	-	-	-	GU90353030	1	
18	Bevel gear Z=8/31	-	-	-	00700N	GU20354621	1	
19	Screw	-	-	-	-	GU19356320	6	
20	Tap.roller bearing	-	-	-	-	GU92249223	1	
21	Spacer 1,1 mm	-	-	-	-	GU19355406	1	
	Spacer 1,6 mm	-	-	-	-	GU19355413	1	
	Spacer 1,5 mm	-	-	-	-	GU19355412	1	
	Spacer 1,4 mm	-	-	-	-	GU19355411	1	
	Spacer 1,2 mm	-	-	-	-	GU19355408	1	
	Spacer 1 mm	-	-	-	-	GU19355404	1	
	Spacer 0,9 mm	-	-	-	-	GU19355402	1	
	Spacer 0,8 mm	-	-	-	-	GU19355400	1	
	Spacer 1,3 mm	-	-	-	-	GU19355410	1	
22	Gasket	-	-	-	-	GU19350700	2	
23	Thrust washer	-	-	-	-	GU19352300	1	
24	Thrust washer	-	-	-	-	GU19353500	1	
25	Screw M8X25	-	-	-	-	GU19357660	7	

26	Spring washer 8x15x0,3	-	-	-	-	-	GU61270300	7
28	Spacer	-	-	-	-	-	GU19356801	1
29	Gasket ring 18,77X1,78	-	-	-	-	-	GU90706188	1
30	Nut	-	-	-	-	-	GU19356700	1
31	Bearing casing	-	-	-	-	-	GU19352401	1
32	Roller bearing 20x47x14	-	-	-	-	-	GU92249220	1
33	Spacer 1,1 mm	-	-	-	-	-	GU19355301	2
	Spacer 1,9 mm	-	-	-	-	-	GU19355309	2
	Spacer 1,8 mm	-	-	-	-	-	GU19355308	2
	Spacer 1,7 mm	-	-	-	-	-	GU19355307	2
	Spacer 1,6 mm	-	-	-	-	-	GU19355306	2
	Spacer 1,5 mm	-	-	-	-	-	GU19355305	2
	Spacer 1,4 mm	-	-	-	-	-	GU19355304	2
	Spacer 1,2 mm	-	-	-	-	-	GU19355302	2
	Spacer 1 mm	-	-	-	-	-	GU19355300	2
	Spacer 1,3 mm	-	-	-	-	-	GU19355303	2
34	Spacer	-	-	-	-	-	GU19355121	1
35	Shim 0,1 mm	-	-	-	-	-	GU19355200	1
36	Shim 0,15 mm	-	-	-	-	-	GU19355202	1
37	Gasket ring	-	-	-	-	-	GU90706552	1
38	Gasket ring	-	-	-	-	-	GU90403247	1
39	Spacer	-	-	-	-	-	GU27634110	2
40	Spacer 1,2 mm	-	-	-	-	-	GU19355322	1
	Spacer 1,9 mm	-	-	-	-	-	GU19355329	1
	Spacer 1,8 mm	-	-	-	-	-	GU19355328	1
	Spacer 1,7 mm	-	-	-	-	-	GU19355327	1
	Spacer 1,6 mm	-	-	-	-	-	GU19355326	1
	Spacer 1,5 mm	-	-	-	-	-	GU19355325	1
	Spacer 1,3 mm	-	-	-	-	-	GU19355323	1
	Spacer 1,1 mm	-	-	-	-	-	GU19355321	1
	Spacer 1 mm	-	-	-	-	-	GU19355320	1
	Spacer 1,4 mm	-	-	-	-	-	GU19355324	1
41	Plate	-	-	-	-	-	GU27357411	1
42	O-ring	-	-	-	-	-	GU90706076	2




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Dashboard box assy.	-	-	-	-	GU23760010	1	
2	Speedometer	-	-	UK	-	GU23762470	1	
3	Speedometer	-	-	-	-	GU31761560	1	
3	Gear 60°	-	-	-	-	GU23768310	2	
4	Tachometer	-	-	UK	-	GU23767270	1	
4	Tachometer	-	-	-	-	GU31767260	1	
5	Rev counter container	-	-	-	-	GU23761910	1	
6	Speedometer container	-	-	-	-	GU23762010	1	
7	Screw	-	-	-	-	GU98622214	2	
8	Spacer	-	-	-	-	GU23765110	2	
9	Plate	-	-	-	-	GU23764910	1	
10	Washer 5,3x8,9x2,4	-	-	-	-	GU95020105	2	
11	Lamp 12v-3w	-	-	-	-	GU93450120	2	
12	Speedometer transmission	-	-	-	-	GU27760410	1	
13	Plate	-	-	-	-	GU23766510	1	
14	Rev counter transmission	-	-	-	-	GU23768110	1	
15	Lower cover	-	-	-	-	GU29765250	1	
16	Self-tap screw	-	-	-	-	GU99210210	2	
17	Lampholder	-	-	-	-	GU19768680	8	
18	Lamp 12V-1,2W	-	-	-	-	GU93450140	8	
19	U-bolt	-	-	-	-	GU31764165	1	
20	Spacer	-	-	-	-	GU23766911	1	
21	Screw	-	-	-	-	GU98054230	1	
22	Washer	-	-	-	-	GU95004205	2	
23	Screw	-	-	-	-	GU98054325	2	
24	Washer 6,15x11x0,8	-	-	-	-	GU95004206	2	
25	Rubber spacer 8x18	-	-	-	-	GU91551167	2	
26	Spacer 6,2x8x13,5	-	-	-	-	GU91180617	2	
27	Nut M6x1	-	-	-	-	GU92630106	2	
28	Turn indicator switch	-	-	-	-	GU28745761	1	
29	Rubber protection	-	-	-	-	GU35755780	1	
30	Key	-	-	-	-	GU31735560	1	
31	Screw	-	-	-	-	GU98054230	1	

32	Spacer	-	-	-	-	-	GU23766910	1
33	Main switch	-	-	-	-	-	GU31735360	1
34	Gear Z=14	-	-	-	-	-	GU14769200	1
35	Reset button	-	-	-	-	-	GU19762810	1
36	Ring nut	-	-	-	-	-	GU19741336	1
37	Main switch	-	-	-	-	-	GU30735060	1
38	Lock hardware kit	-	-	-	-	-	GU31736881	1




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Headlight	W-X	-	AUS-MAL-NZ-UK	LF	-	GU31740520	1
	Optical group	1-Y	-	-	00700N-T1	-	GU31740581	1
	Headlight	1-Y	-	AUS-MAL-NZ-UK	00700N-T1	-	GU31740582	1
	Headlight	W-X	-	-	LF	-	GU28740533	1
2	Light frame	-	-	-	-	-	GU19740454	1
3	Optical group	W-X	-	AUS-MAL-NZ-UK	LF	-	GU31740420	1
	Optical group	1-Y	-	-	00700N-T1	-	GU02740400	1
	Optical group	1-Y	-	AUS-MAL-NZ-UK	00700N-T1	-	GU02740504	1
	Optical group	W-X	-	-	LF	-	GU18740435	1
4	Lamp 12V-55/60W	-	-	-	-	-	GU93450232	1
5	Lampholder	-	-	-	-	-	GU14756255	1
6	Rear cap	1-Y	-	-	00700N-T1	-	GU02740458	1
	Headlight body	W-X	-	-	LF	-	GU23740418	1
7	Rear cap plug	-	-	-	-	-	GU19740404	1
8	Washer	1-Y	-	-	00700N-T1	-	GU95004208	2
	Washer 10,2x18x2	W-X	-	-	LF	-	GU95004210	2
9	Screw	1-Y	-	-	00700N-T1	-	GU98230831	2
	Screw	W-X	-	-	LF	-	GU98231023	2
10	Adjuster screw	-	-	-	-	-	GU19740303	1
11	Lampholder	-	-	-	-	-	GU17740405	1
12	Lamp 12V-4W	-	-	-	-	-	GU93450119	1
13	RH front turn indicator	-	-	-	-	-	GU31750665	1
	LH front turn indicator	-	-	-	-	-	GU31750666	1
14	Screw	-	-	-	-	-	GU19740302	1
15	Lamp 12V-10W	-	-	-	-	-	GU93450127	2
16	Turn indicator lens	-	-	-	-	-	GU31753765	2
17	Horn H	-	-	-	-	-	GU31743765	1
18	Horn L	-	-	-	-	-	GU31743766	1
19	Screw	-	-	-	-	-	GU98230816	1


20	Screw	-	-	-	-	-	GU98612320	2
21	Nut	-	-	-	-	-	GU92660208	1
22	Horn support plate	-	-	-	-	-	GU31744265	1
23	Horn mask	-	-	-	-	-	GU31744765	2
24	Screw	-	-	-	-	-	GU98230616	2
25	Washer	-	-	-	-	-	GU95000206	2
26	Nut M6x1	-	-	-	-	-	GU92630106	2
27	Headlight wiring w/harness	1-Y	-	-	00700N-T1	-	GU31746981	1
28	Rubber spacer	1-Y	-	-	00700N-T1	-	GU91551105	1
29	Spacer	1-Y	-	-	00700N-T1	-	GU31439881	2




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Taillight	-	-	-	-	GU31740960	1	
2	Taillight lens	-	-	-	-	GU31741760	1	
3	Lamp 12V/5-21W	-	-	-	-	GU93450224	1	
4	Spacer	-	-	-	-	GU31741260	1	
5	Rear RH turn indicator	-	-	-	-	GU31751665	1	
6	Rear LH turn indicator	-	-	-	-	GU31751666	1	
7	Lamp 12V-10W	-	-	-	-	GU93450127	2	
8	Turn indicator lens	-	-	-	-	GU31753765	2	
9	Nut	-	-	-	-	GU92602312	2	
10	Notched washer	-	-	-	-	GU95021112	2	
11	Nut M6x1	-	-	-	-	GU92630106	2	
12	Washer	-	-	-	-	GU95000206	2	
13	Rubber spacer	-	-	-	-	GU93110060	2	




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Lower side filter case	-	-	-	-	GU19114060	1	
2	Air filter	-	-	-	-	GU28113650	1	
3	Bracket	-	-	-	-	GU19112960	1	
4	Gasket	-	-	-	-	GU19113960	1	
5	Protection	-	-	-	-	GU19111060	1	
6	Cover	-	-	-	-	GU19111160	1	
7	Filter cover	-	-	-	-	GU19113760	1	
8	Short spring	-	-	-	-	GU31110715	3	
9	Upper side filter case	-	-	-	-	GU19113460	1	
10	Lenght spring	-	-	-	-	GU31110815	3	
11	Air filter support	-	-	-	-	GU31114165	1	
12	Screw	-	-	-	-	GU98054214	1	
13	Notched washer	-	-	-	-	GU95021105	1	
14	Washer	-	-	-	-	GU95000205	1	
15	Nut	-	-	-	-	GU92630105	1	
16	Housing	-	-	-	00700N	GU31153481	1	
17	Breather	-	-	-	-	GU23159671	1	
18	Hose clamp	-	-	-	-	GU93305018	3	
19	Hose clamp	-	-	-	-	GU19609600	3	
20	Breather	-	-	-	-	GU27159360	1	
21	Pipe	-	-	-	-	GU27157420	1	
22	Hose clamp	-	-	-	-	GU61108400	1	
23	Rubber spacer	-	-	-	-	GU14423800	1	
24	Gasket	-	-	-	-	GU27113985	1	
25	Hose clamp D9	-	-	-	-	GU61108500	1	
26	Rubber pipe 5X9	-	-	-	-	GU00823944050	1	
27	Thermal sheath	-	-	-	-	GU00823923140	1	
28	Hose clamp	-	-	-	-	GU27609685	1	
29	Guard	-	-	-	-	GU31111265	1	
30	Self-tap screw	-	-	-	-	GU99200413	3	
31	Square	-	-	-	-	GU31112965	1	
32	Gasket	-	-	-	-	GU90714082	1	




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Front fork	-	-	-	-	GU31490265	1	
2	Tap.roller bearing	-	-	-	-	GU92249225	2	
3	Cup	-	-	-	-	GU14494600	1	
4	Clearance washer	-	-	-	-	GU14516700	1	
5	Dust cover	-	-	-	-	GU14517000	1	
6	BITUBO shock absorber	-	-	-	-	GU31550281	1	
7	Pin	-	-	-	-	GU23555281	1	
8	Spacer	-	-	-	-	GU95100235	1	
9	Screw	-	-	-	-	GU98822416	1	
10	Pin	-	-	-	-	GU23555280	1	
11	Washer 10,5X18X0,8	-	-	-	-	GU95129180	1	
12	Spring washer 8x15x0,3	-	-	-	-	GU61270300	2	
13	Nut	-	-	-	-	GU92602410	1	
14	Screw	-	-	-	-	GU98230826	2	
15	Spacer	-	-	-	-	GU31469281	2	
16	O-ring	-	-	-	-	GU90706092	2	
17	Spacer 8,5x12x4	-	-	-	-	GU91180804	2	
18	Spacer	-	-	-	-	GU91181407	2	
19	Washer	-	-	-	-	GU23557690	2	
20	Indicator support mask	-	-	-	-	GU31751365	1	
21	Washer	-	-	-	-	GU95100256	2	
22	Adhesive dataplate	-	-	-	-	GU30769560	1	
23	Shock-absorbersadjustment key	-	-	-	-	GU31912760	1	





Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Transmission assygrey	-	-	-	-	GU31350280	1	
2	Hose	-	-	-	-	GU19327701	1	
3	Hose	-	-	-	-	GU19328801	1	
4	Circlip	-	-	-	-	GU90272023	1	
5	Disc	-	-	-	-	GU19327601	1	
6	Spring	-	-	-	-	GU94321099	1	
7	Coupling	-	-	-	-	GU23328081	1	
8	Protection collar	-	-	-	-	GU23548080	1	
9	Spring	-	-	-	-	GU23548180	1	
10	Hose clamp	-	-	-	-	GU93305074	1	
11	Rear fork grey	-	-	-	-	GU31540281	1	
12	Pin	-	-	-	-	GU19547000	2	
13	Spacer	-	-	-	-	GU35214300	1	
14	Nut	-	-	-	-	GU14547800	2	
16	Screw	-	-	-	-	GU98620545	1	
17	Washer 10,2x18x2	-	-	-	-	GU95004210	1	
18	Nut	-	-	-	-	GU92602210	1	
19	Nut	-	-	-	-	GU92781081	4	
20	Washer 8,4X13X0,8	-	-	-	-	GU14615901	4	
21	Plug	-	-	-	-	GU93180105	2	
22	Washer	-	-	-	-	GU95004208	4	
23	Pin	-	-	-	-	GU31544160	1	
24	Washer 14,5X20X1	-	-	-	-	GU95100523	1	
25	Split pin	-	-	-	-	GU95500222	1	




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Electrical system	1-X-Y	-	-	02399N- DU	-	GU31747182	1
	Electrical system	W	-	-	SA	-	GU31747181	1
2	Dashboard cable	-	-	-	-	-	GU31747267	1
3	Taillight wiring harn.	-	-	-	-	-	GU31747365	1
4	Neutral sensor cable	-	-	-	-	-	GU31724540	1
5	RH clamp	-	-	-	-	-	GU30477101	1
6	LH plate	-	-	-	-	-	GU30477200	1
7	Relay Siemens A302/B1008	-	-	-	-	-	GU30732560	4
8	Flasher unit	-	-	-	-	-	GU17750520	1
	Flasher unit	-	-	AUS	-	-	GU31750560	1
9	Fuse 15A	-	-	-	-	-	GU28742560	4
10	Fuse holder box	-	-	-	-	-	GU30732200	4
11	Support	-	-	-	-	-	GU30756100	1
12	Relais support	-	-	-	-	-	GU30732400	4
13	Hex socket screw M6X18	-	-	-	-	-	GU98622318	2
14	Washer 6,15x11x0,8	-	-	-	-	-	GU95004206	2
15	Washer	-	-	-	-	-	GU95100120	2
16	Nut M6x1	-	-	-	-	-	GU92630206	2
17	Clamp	-	-	-	-	-	GU31749765	1
18	Screw	-	-	-	-	-	GU61127520	1
19	Ring nut	-	-	-	-	-	GU61127220	1
20	Hose clamp 3,6x20,6	-	-	-	-	-	GU14609650	1
21	Spacer	-	-	-	-	-	GU91180607	2
22	Rubber spacer	-	-	-	-	-	GU92551085	2
23	Ground-battery lead	-	-	AUS	-	-	GU31755660	1




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Handlebar	-	-	-	-	GU31600381	1	
2	Throttle pipe w/out hand grip	-	-	-	-	GU30603800	1	
3	RH hand grip	-	-	-	-	GU31603565	1	
4	RH lights selector	-	-	-	-	GU30738860	1	
5	Throttle cable	-	-	-	T2	GU31117565	1	
	Gas lever transmission	-	-	-	01101N-T3	GU31117581	1	
6	Splitter	-	-	-	T2	GU30607910	2	
	Splitter	-	-	-	01101N-T3	GU31607981	2	
7	Hose clamp 3,6x20,6	-	-	-	-	GU14609650	2	
8	Throttle cable	-	-	-	T2	GU27117775	2	
	Gas lever transmission	-	-	-	01101N-T3	GU31117781	2	
9	Choke control	-	-	-	-	GU30135200	1	
10	LH lights selector	-	-	-	-	GU30738060	1	
11	LH hand grip	-	-	-	-	GU31603065	1	
12	Choke cable	-	-	-	01101N-T3	GU31132881	1	
	Choke cable	-	-	-	T2	GU31132865	1	
13	Choke cable	-	-	-	-	GU27133515	2	
14	Clutch lever cpl.	-	-	-	-	GU30605560	1	
15	Nut	-	-	-	-	GU92602206	1	
16	Bear clutch lever supp.	-	-	-	-	GU30601800	1	
17	Lever pin	-	-	-	-	GU30530528	1	
18	Register	-	-	-	-	GU30602500	1	
19	Clutch cable	-	-	-	-	GU31093065	1	
20	Bellows	-	-	-	-	GU23093870	1	
21	Rearview mirror	-	-	-	03499N-2A	GU03769400	2	
	Rearview mirror	-	-	-	1A	GU31769465	2	
22	Nylon washer	-	-	-	-	GU30606900	1	
23	Hose clamp L36 mm	-	-	-	-	GU03609600	1	
24	Gas lever transmission	-	-	-	01101N-T3	GU31117081	1	
25	Starter transmission compl.	-	-	-	01101N-T3	GU31137081	1	



		NEVADA CLUB 750 1998-2001	GU018	00	TAB N.	16		
FRONT/REAR MUDGUARD								
								
Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Front mudguard, black	W-X	-	-	LF	-	GU89000213	1
	Front mudguard, white	1-Y	-	-	00700N-T1	white	GU89000317	1
	Front mudguard, red	1-Y	-	-	00700N-T1	red	GU89000318	1
	Front mudguard blu	1-Y	-	-	00700N-T1	blue	GU89000319	1
	Front mudguard, black	1-Y	-	-	00700N-T1	m.bla	GU89000320	1
	Front mudguard, white	-	-	-	gr	-	GU314344651	1
2	Stabilization plate	-	-	-	-	-	GU31436665	1
3	Screw	-	-	-	-	-	GU98230826	4
4	O-ring	-	-	-	-	-	GU90706092	8
5	Spacer	-	-	-	-	-	GU91180829	4
6	Eyelet	-	-	-	03401N-T7	-	GU13436561	2
	Eyelet	-	-	-	-	-	GU28659740	2
7	Nut M6x1	-	-	-	-	-	GU92630206	6
8	Screw	-	-	-	-	-	GU31439565	4
9	Rear mudguard blank	-	-	-	01101N-gr-T3	-	GU31437074	1
	Rear mudguard, black	W-X	-	-	LF	-	GU89000216	1
	Rear mudguard, white	1-Y	-	-	00700N-T1	white	GU89000321	1
	Rear mudguard, red	1-Y	-	-	00700N-T1	red	GU89000322	1
	Rear mudguard, blue	1-Y	-	-	00700N-T1	blue	GU89000323	1
	Rear mudguard, black	1-Y	-	-	00700N-T1	m.bla	GU89000324	1
	Rear mudguard, white	1-Y	-	-	01101N-T3	white	GU89000376	1
	Rear mudguard, red	1-Y	-	-	01101N-T3	red	GU89000377	1
	Rear mudguard, blue	1-Y	-	-	01101N-T3	blue	GU89000378	1
	Rear mudguard, black	1-Y	-	-	01101N-T3	m.bla	GU89000379	1
	Rear mudguard blank	-	-	-	gr-T2	-	GU31437073	1
10	Rear mudguard supp.	-	-	-	-	-	GU31439160	1
11	Hex screw M6X20	-	-	-	-	-	GU98054320	6
12	Washer	-	-	-	-	-	GU95000206	10
13	Rubber spacer	-	-	-	-	-	GU93110060	2
14	Washer 6,4x12x1,2	-	-	-	-	-	GU95100141	2




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	LH footrest support	-	-	-	-	GU23446010	1	
2	RH footrest support	-	-	-	-	GU23443510	1	
3	Spring washer 8x15x0,3	-	-	-	-	GU61270300	4	
4	Screw	-	-	-	-	GU98622420	4	
5	Bush	-	-	-	-	GU29436450	2	
6	Footrest plate	-	-	-	-	GU66441730	2	
7	Spring washer	-	-	-	-	GU95021108	2	
8	Spring washer 8x15x0,3	-	-	-	-	GU61270300	2	
9	Nut	-	-	-	-	GU92630508	2	
10	Screw	-	-	-	-	GU98250830	2	
11	Stop ring	-	-	-	-	GU90280006	2	
12	Pin	-	-	-	-	GU66440630	2	
13	RH front foot rest pipe	-	-	-	-	GU66440730	1	
14	LH front foot rest pipe	-	-	-	-	GU66441830	1	
15	Spacer	-	-	-	-	GU66441630	2	
16	Spring washer	-	-	-	-	GU51609800	2	
17	Foot rest	-	-	-	-	GU66443230	2	
18	Plate	-	-	-	-	GU31441260	2	
19	Screw	-	-	-	-	GU98304014	2	
20	Rubber spacer	-	-	-	-	GU93180206	1	
21	Plug	-	-	-	-	GU23943410	5	




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Rear brake caliper	-	-	-	01101N-T3	-	GU31653081	1
	Rear brake caliper	-	-	-	T2	-	GU23653011	1
2	Pads pair BREMBO	-	-	-	T2	-	GU27654610	1
	Pads pair	-	-	-	01101N-T3	-	GU31654681	1
3	Brake hanger plate	-	-	-	T2	-	GU27635811	1
	Brake hanger plate	-	-	-	01101N-T3	-	GU31635881	1
4	Bush	-	-	-	-	-	GU31634230	1
5	Spacer	-	-	-	-	-	GU31634130	1
6	Brake hose	-	-	-	-	-	GU28657500	1
7	Oil pipe screw *	-	-	-	-	-	GU95990028	3
8	Gasket	-	-	-	-	-	GU25656100	7
9	Screw	-	-	-	-	-	GU98612425	2
10	Spring washer 8x15x0,3	-	-	-	-	-	GU61270300	2
11	Washer	-	-	-	-	-	GU95000206	1
12	Pins+Caliper springs BREMBO	-	-	-	T2	-	GU23659111	1
	Pads kit	-	-	-	01101N-T3	-	GU31659181	1
13	Bleeder+cap BREMBO D.10	-	-	-	T2	-	GU31659260	1
	Bleeder+cap	-	-	-	01101N-T3	-	GU31659281	1
14	Nut M8X1,25	-	-	-	-	-	GU92602208	1
15	U-bolt	-	-	-	-	-	GU93301313	1
16	Connection	-	-	-	-	-	GU19668000	1
17	Switch	-	-	-	-	-	GU63657000	1
18	Screw	-	-	-	-	-	GU98622310	1


		NEVADA CLUB 750 1998-2001	GU018	00	TAB N.	19		
FRONT MASTER CILINDER								
								
Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Front master cilinder	-	-	-	-	GU30660180	1	
2	Front master cilinder	-	-	-	-	GU28660178	1	
3	Brake lever	-	-	-	-	GU30605680	1	
4	Bracket	-	-	-	-	GU27664075	1	
5	Pin	-	-	-	-	GU27604815	1	
6	Cap	-	-	-	-	GU27663615	1	
7	Microswitch	-	-	-	-	GU30749860	1	
8	Screw	-	-	-	-	GU98200214	2	
9	Ball	-	-	-	-	GU92295708	1	
10	Pump cover	-	-	-	-	GU27661115	1	
11	Pump revision kit	-	-	-	-	GU28659378	1	
12	Oil pipe screw *	-	-	-	-	GU95990028	3	
13	Front brake hose	-	-	-	-	GU31657165	1	
14	Distributor	-	-	-	-	GU31656860	1	
15	LH front brake caliper Grimeca	-	-	-	GRI	GU31652265	1	
16	RH front brake caliper Grimeca	-	-	-	GRI	GU31652365	1	
17	Brake caliper cover GRIMECA	-	-	-	GRI	GU31654765	2	
18	Pads pair GRIMECA	-	-	-	GRI	GU31654665	2	
19	Gasket	-	-	-	-	GU25656100	6	
20	Screw	-	-	-	-	GU98622422	3	
21	Spring washer 8x15x0,3	-	-	-	-	GU61270300	4	
22	Washer 8,5X18X0,5	-	-	-	-	GU95100250	1	
	Washer 8,5X18X0,8	-	-	-	-	GU95100251	1	
23	Bleeder+cap GRIMECA	-	-	-	GRI	GU31659265	2	
24	Pins+spring GRIMECA	-	-	-	GRI	GU31659165	2	
25	Brake caliper rev. kit GRIMECA	-	-	-	GRI	GU66659031	2	
26	Nut	-	-	-	-	GU92601002	2	
27	Hex socket screw M8X25	-	-	-	-	GU98622425	1	
28	Cable-guide	-	-	-	-	GU23655770	1	
29	Ring	-	-	-	-	GU91551120	1	
30	Cap	-	-	-	-	GU39663801	1	
31	Screw	-	-	-	-	GU98230630	1	
32	Spacer	-	-	-	-	GU91180605	1	
33	Nut M6x1	-	-	-	-	GU92630106	1	
34	Front brake hose	-	-	-	-	GU31658865	2	



Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Brake lever	-	-	-	-	GU31677081	1	
2	Rubber spacer	-	-	-	-	GU14251001	1	
3	Spring washer	-	-	-	-	GU95129260	1	
4	Flat washer	-	-	-	-	GU95004215	1	
5	Split pin	-	-	-	-	GU95500227	1	
6	Tie rod	-	-	-	-	GU31675280	1	
7	Block	-	-	-	-	GU18257551	1	
8	Nut	-	-	-	-	GU92690073	2	
9	Fork	-	-	-	-	GU31626860	1	
10	Pin	-	-	-	-	GU95770265	1	
11	Washer	-	-	-	-	GU95129110	1	
12	Split pin	-	-	-	-	GU95500222	1	
13	Rear master cylinder	-	-	-	-	GU31666990	1	
14	Pump connection overhaul unit	-	-	-	-	GU19659500	1	
15	O-ring	-	-	-	-	GU90706141	1	
16	Screw	-	-	-	-	GU98822316	2	
17	Screw M6X30	-	-	-	-	GU98620330	2	
18	Washer	-	-	-	-	GU95000206	4	
19	Hose clamp	-	-	-	-	GU19157800	2	
20	Nut M6x1	-	-	-	-	GU92630106	2	
21	Brake oil tank	-	-	-	-	GU65663500	1	
22	Circlip	-	-	-	-	GU90271008	1	
23	Tank cap	-	-	-	-	GU17661052	1	
24	Rear brake hose	-	-	-	-	GU00823950050	1	




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Luggage rack kit	-	-	-	-	GU31676282	1	
2	Parcel rack assy	W-X	-	-	LF	GU31466581	1	
	Parcel rack assy	1-Y	-	-	00700N-T1	GU31466582	1	
3	Seat cushion	W-X	-	-	LF	GU03468000	1	
	Seat cushion	1-Y	-	-	00700N-T1	GU31468082	1	
4	Cover	1-Y	-	-	00700N-T1	GU31468282	1	
	Cover	W-X	-	-	LF	GU03468200	1	
5	Hex socket screw M6x18	-	-	-	-	GU98230619	2	
6	Ball	-	-	-	-	GU92295708	1	
7	Spring	-	-	-	-	GU94321007	1	
8	Screw	-	-	-	-	GU31468165	2	
9	Washer 6,15x11x0,8	-	-	-	-	GU95004206	2	
10	Nut	-	-	-	-	GU92601206	2	
11	Clamp	-	-	-	-	GU31575565	2	
12	Screw	-	-	-	-	GU98231023	2	
13	Rubber spacer	-	-	-	-	GU91551085	2	




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Splash guard	-	-	-	-	GU31438665	1	
2	Fixing snap	-	-	-	-	GU29728960	1	
3	Rubber spacer	-	-	-	-	GU93180060	2	
4	Screw	-	-	-	-	GU98054325	2	
5	Washer	-	-	-	-	GU95000206	10	
6	Washer	-	-	-	01101N-T3	GU91551108	10	
	Rubber spacer	-	-	-	T2	GU93110060	10	
7	Washer	-	-	-	01101N-T3	GU95100120	9	
	Washer 6,4x12x1,2	-	-	-	T2	GU95100141	9	
8	Nut M6x1	-	-	-	-	GU92630106	4	
9	Operator's handbook -I-D-F-UK-	-	-	D-F-I-UK	-	GU31900068	1	
10	Gasket	-	-	-	-	GU00823931070	1	
11	Toolkit	-	-	-	-	GU20909920	1	
12	Plug	-	-	-	-	GU93180245	2	
13	RH frame protection	-	-	-	T4	GU31457865	1	
	RH rear cover chromate	-	-	-	01701N-T5	GU31457866	1	
14	LH frame protection	-	-	-	T4	GU31459165	1	
	LH rear cover chromate	-	-	-	01701N-T5	GU31459166	1	
15	Plate	-	-	-	-	GU31575560	2	
16	Rear mudg. extension	-	-	-	01101N-T3	GU31438066	1	
	Number-plate extension	-	-	-	T2	GU31438065	1	
17	Number plate holder	-	-	-	00700N	GU01474630	1	
18	Reflector	-	-	-	-	GU31745865	1	
19	Nut M4x0,7	-	-	-	-	GU92630104	2	
20	Nut	-	-	-	-	GU92630105	4	
21	Screw	-	-	-	-	GU98054212	4	
22	O-ring	-	-	-	-	GU90706035	4	
23	Washer	-	-	-	-	GU95000205	4	
24	Hex screw M6X16	-	-	-	T2	GU98054316	3	
	Screw	-	-	-	01101N-T3	GU98052325	3	
25	U-bolt	-	-	-	-	GU93301313	1	


26	Nut M6x1	-	-	-	-	-	GU92630206	2
27	Screw	-	-	-	-	-	GU98054314	2
28	Captive nut	-	-	-	-	-	GU92660601	3
29	Adhesive gasket	-	-	-	-	-	GU29579460	1
30	Spacer	-	-	-	-	-	GU91180611	3
31	Screw M6X50	-	-	-	01701N-T5	-	GU98230650	2
32	Washer	-	-	-	01701N-T5	-	GU03462800	2
33	Rubber spacer	-	-	-	01701N-T5	-	GU91551105	2
34	Spacer	-	-	-	01701N-T5	-	GU03471802	2



Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Front wheel 2,15x18"	-	-	-	-	GU31610365	1	
2	Spoke	-	-	-	-	GU39611601	36	
3	Counterweight 15 gr.	-	-	-	-	GU12616101	1	
	Counterweight 20 gr.	-	-	-	-	GU12616102	1	
	Counterweight 30 gr.	-	-	-	-	GU12616103	1	
4	Flange	-	-	-	-	GU31620365	2	
5	Spacer	-	-	-	-	GU31615260	1	
6	Bearing	-	-	-	-	GU92204221	2	
7	Washer 17X27X2	-	-	-	-	GU95004217	1	
8	Nut M16X1,5	-	-	-	-	GU92602516	1	
9	Name plate "Moto Guzzi"	-	-	-	-	GU31619865	2	
10	Screw	-	-	-	-	GU30611460	10	
11	Screw	-	-	-	-	GU98052470	5	
12	Washer 8,4X13X0,8	-	-	-	-	GU14615901	5	
13	Nut	-	-	-	-	GU92630508	5	
14	Front wheel spindle	-	-	-	-	GU31614160	1	
15	Spacer	W-Y	-	-	-	GU31616361	2	
16	Front wheel 2,15x18"	-	-	-	-	GU23610870	1	
17	Brake disc	-	-	-	-	GU30635860	2	
18	Flange	-	-	-	-	GU30613760	2	
19	Bush	-	-	-	-	GU28613560	10	
20	Belleville spring	-	-	-	-	GU28618860	10	
21	Circlip	-	-	-	-	GU90271022	10	
22	Odometer gear	W-X-Y	-	-	-	GU31762561	1	
	Speedometer gear	1	-	-	03600N	GU31762562	1	
23	Spacer	W-Y-Y	-	-	-	GU31616360	2	
24	Nipple	-	-	-	-	GU55611700	36	
25	Ring	1	-	-	03600N	GU31677162	1	




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Rear wheel(complete)	-	-	-	-	GU31630365	1	
2	Brake disc	-	-	-	T2	GU31613380	1	
	Brake disc	-	-	-	01101N-T3	GU31613381	1	
3	Hex socket screw M8X25	-	-	-	-	GU98622425	6	
4	RH rubber coupling	-	-	-	-	GU19632501	6	
5	LH rubber coupling	-	-	-	-	GU19632502	6	
6	Bearing	-	-	-	-	GU92204218	1	
7	Bearing	-	-	-	-	GU92204217	1	
8	Spacer	-	-	-	-	GU27633910	1	
9	Spacer	-	-	-	-	GU27356910	1	
10	Rear wheel spindle	-	-	-	01101N-T3	GU31633381	1	
	Rear wheel spindle	-	-	-	T2	GU31633330	1	
11	Washer	-	-	-	-	GU14634400	1	
12	Nut M6X1,5	-	-	-	-	GU92602316	1	
13	Long spoke	-	-	-	-	GU23631470	18	
14	Short spoke	-	-	-	-	GU23631170	18	
15	Nipples	-	-	-	-	GU27631250	36	
16	Counterweight 15 gr.	-	-	-	-	GU12616101	1	
	Counterweight 20 gr.	-	-	-	-	GU12616102	1	
	Counterweight 30 gr.	-	-	-	-	GU12616103	1	
17	Rear wheel 250x16"	-	-	-	-	GU23630770	1	
18	Name plate "Moto Guzzi"	-	-	-	-	GU31619865	1	





Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Saddle	1-Y	-	-	00700N-T1	-	GU31460582	1
	Driver saddle	W-X	-	-	LF	-	GU31460576	1
2	Rear saddle	W-X	-	-	LF	-	GU31464081	1
3	Rubber spacer	-	-	-	-	-	GU93110082	2
4	Washer 6,4x12x1,2	-	-	-	-	-	GU95100141	4
5	Nut M6x1	-	-	-	-	-	GU92630206	4
6	RH front protect chrome	-	-	-	-	-	GU31469081	1
7	LH front protect chrome	-	-	-	-	-	GU31469181	1
8	Screw	-	-	-	-	-	GU98230826	2
9	Spacer	-	-	-	-	-	GU31469281	2
10	O-ring	-	-	-	-	-	GU90706092	2
11	RH side cover black	1-Y	-	-	00700N-T1	m.bla	GU89000328	1
	RH side cover blank	-	-	-	gr	-	GU234762101	1
	RH side cover black	W-X	-	-	CLUB-LF	-	GU89000219	1
	RH side cover black	W-X	-	-	00699N-BASE-LF	-	GU89000301	1
	RH side cover white	1-Y	-	-	00700N-T1	white	GU89000325	1
	RH side cover red race	1-Y	-	-	00700N-T1	red	GU89000326	1
	R.H. side cover blue	1-Y	-	-	00700N-T1	blue	GU89000327	1
12	L.H. side cover blue	1-Y	-	-	00700N-T1	blue	GU89000331	1
	LH side cover black	1-Y	-	-	00700N-T1	m.bla	GU89000332	1
	LH side cover red race	1-Y	-	-	00700N-T1	red	GU89000330	1
	LH side cover white	1-Y	-	-	00700N-T1	white	GU89000329	1
	LH side cover black	W-X	-	-	00699N-BASE-LF	-	GU89000302	1
	LH side cover black	W-X	-	-	CLUB-LF	-	GU89000222	1
	LH side cover blank	-	-	-	gr	-	GU314763621	1
13	Decal Nevada 750 Club	W-X	-	-	LF	-	GU31922068	2
	Nevada Base decal,silver/black	1-Y	-	-	00700N-T1	-	GU31922069	2

	Decal Nevada Club silv/bla	1-Y	-	-	00700N-T1	-	GU31922070	2
	Decal "Nevada 750"	W-X	-	-	00699N-BASE-LF	-	GU31922067	2
14	Fuse table decal	-	-	-	-	-	GU31945467	1
15	Saddles	-	-	-	-	-	GU31460581	1
16	Cover decal	1-Y	-	-	00700N-T1	-	GU14922071	2
17	Saddle button	-	-	-	01101N	-	GU00979719	7




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Fuel tank, black/orange	W-X	-	-	LF	bl/or	GU89000207	1
	Fuel tank, black/green	W-X	-	-	LF	bl/ve	GU89000208	1
	Fuel tank red/black	W-X	-	-	LF	bl/re	GU89000209	1
	Fuel tank grey iron/black	W-X	-	-	LF	bl/gr	GU89000210	1
	Fuel tank, black	W-X	-	-	00699N-BASE-LF	-	GU89000262	1
	Fuel tank white	1-Y	-	-	00700N-T1	white	GU89000313	1
	Fuel tank red	1-Y	-	-	00700N-T1	red	GU89000314	1
	Fuel tank blue	1-Y	-	-	00700N-T1	blue	GU89000315	1
	Fuel tank, black	1-Y	-	-	00700N-T1	m.bla	GU89000316	1
	Fuel tank blank	-	-	-	gr	-	GU31100283	1
2	"Moto Guzzi" LH decal	1-Y	-	-	00700N-T1	-	GU01917900	1
	"MotoGuzzi"RH decal,gold/black	W-X	-	-	LF	-	GU30917860	1
	"Moto Guzzi" RH decal	1-Y	-	-	00700N-T1	-	GU01917800	1
	"MotoGuzzi"LH decal,gold/black	W-X	-	-	LF	-	GU30917960	1
3	Gasket	-	-	-	-	-	GU00823931070	1
4	Tank cap	-	-	-	-	-	GU03103900	1
5	Flange	-	-	-	-	-	GU03101900	1
6	Screw	-	-	-	-	-	GU03103200	2
7	Ring	-	-	-	-	-	GU03103500	2
8	Gasket	-	-	-	-	-	GU03102400	1
9	Plug ring nut	-	-	-	-	-	GU03102200	1
10	Gasket	-	-	-	-	-	GU03101600	1
11	Reduction 38 mm	-	-	-	-	-	GU03101720	1
	Reduction 22 mm	-	-	-	CAT	-	GU03101701	1
12	Sticker	-	-	-	CAT	-	GU29995735	2
13	Screw	-	-	-	-	-	GU98230830	1
14	Washer	-	-	-	-	-	GU95100239	1
15	Spacer	-	-	-	-	-	GU31103565	1
16	Rubber spacer	-	-	-	-	-	GU91551131	1
17	Captive nut	-	-	-	-	-	GU92660801	8
18	Rubber pipe 5X9	-	-	-	-	-	GU00823944050	1



19	Fuel level sensor	-	-	-	-	-	GU31103081	1
20	Fuel solenoid valve	-	-	-	-	-	GU37105305	1
21	Hose clamp	-	-	-	-	-	GU93305017	1
22	Rubber pipe 12,5X7,8 5/16"	-	-	-	-	-	GU00823956080	1
23	Hose clamp	-	-	-	-	-	GU28157950	5
24	3-way union	-	-	-	-	-	GU29106860	1
25	RH side chromium plated	-	-	-	-	-	GU31570681	1
26	LH side chromium plated	-	-	-	-	-	GU31570781	1
27	Screw 6X25	-	-	-	-	-	GU98230626	2
28	Washer 6,15x11x0,8	-	-	-	-	-	GU95004206	4
29	Captive nut	-	-	-	-	-	GU92660601	6
30	Screw M6X20	-	-	-	-	-	GU98230621	2
31	RH front protect black	-	-	-	-	-	GU31575365	1
32	LH front protect black	-	-	-	-	-	GU31575465	1
33	Screw	-	-	-	-	-	GU98230620	4
34	Washer	-	-	-	-	-	GU95001206	4
35	Decal "Attention"	-	-	-	01101N- T3	-	GU30944300	1


		NEVADA CLUB 750 1998-2001	GU018	00	TAB N.	27		
FRONT FORK								
								
Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Lower plate	-	-	-	-	GU31494065	1	
2	Stem plug washer	-	-	-	-	GU18513560	1	
3	Screw	-	-	-	-	GU98612535	2	
4	Spacer	-	-	-	-	GU23497910	2	
5	Anti-rubbing pipe	-	-	-	-	GU23526370	2	
6	Plug	-	-	-	-	GU18513460	1	
7	Fork upper plate POLIZIA	-	-	-	-	GU31493140	1	
8	Screw	-	-	-	-	GU98610540	2	
9	Screw	-	-	-	-	GU98612535	1	
10	Steering lock bush	-	-	-	-	GU18516660	1	
11	RH sleeve	-	-	-	-	GU31522565	1	
12	LH sleeve	-	-	-	-	GU31522665	1	
13	Oil seal	-	-	-	-	GU90403857	2	
14	Bush	-	-	-	-	GU20527620	2	
15	Screw	-	-	-	-	GU98622320	2	
16	Washer 6,25x10x1,5	-	-	-	-	GU95100116	4	
17	Sleeve	-	-	-	-	GU23525470	2	
18	Dust cover	-	-	-	-	GU31524550	2	
19	Shock absorber	-	-	-	-	GU23526470	2	
20	Return spring	-	-	-	-	GU23526610	2	
21	End stop	-	-	-	-	GU28527540	2	
22	Spring	-	-	-	-	GU23526910	2	
23	Screw	-	-	-	-	GU98620545	2	
24	Screw	-	-	-	-	GU98622530	2	
25	Bored screw	-	-	-	-	GU28556450	1	
26	Air valve	-	-	-	-	GU28556250	1	
27	Gasket ring	-	-	-	-	GU90706282	2	
28	Copper washer	-	-	-	-	GU28556350	4	
29	Front shock absorber tube	-	-	-	-	GU19529660	1	
30	Nut	-	-	-	-	GU92602210	2	
31	Cup	-	-	-	-	GU28526540	2	
32	Flat washer	-	-	-	-	GU27499120	2	
33	RH support	-	-	-	-	GU31496165	1	

34	LH support	-	-	-	-	-	GU31496265	1
35	Hex socket screw M8X25	-	-	-	-	-	GU98622425	2
36	O-ring 9x2	-	-	-	-	-	GU90706094	2
37	Spacer	-	-	-	-	-	GU23527910	2
38	Nut	-	-	-	-	-	GU92602308	2
39	Screw M8X35	-	-	-	-	-	GU98620435	4
40	Handlebar fixing plate	-	-	-	-	-	GU23500210	1
41	Reflector, amber	-	-	-	-	-	GU31781665	2




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Frame	-	-	-	-	GU31400181	1	
2	Steering lock	-	-	-	-	GU31782581	1	
3	Drift	-	-	-	-	GU19705900	2	
4	Screw 25 mm	-	-	-	-	GU98622525	4	
5	Washer	-	-	-	-	GU95120105	4	
6	Nut	-	-	-	-	GU92602210	6	
7	Plate	-	-	-	-	GU27418210	1	
8	Screw	-	-	-	-	GU98054418	4	
9	Washer	-	-	-	-	GU95004208	5	
10	Rubber spacer	-	-	-	-	GU91551085	4	
11	Drift	-	-	-	-	GU39103400	2	
12	Washer 8,4x15x1,8	-	-	-	-	GU95100253	2	
13	Pin M10x205	-	-	-	-	GU98110199	1	
14	Washer 10,2x18x2	-	-	-	-	GU95004210	7	
15	Screw	-	-	-	-	GU98620555	2	
16	Handle	-	-	-	-	GU30464310	1	
17	Transfer	-	-	-	-	GU30920810	2	
18	Nut	-	-	-	-	GU92630108	1	
19	Helmet lock	-	-	-	-	GU66466815	1	
20	Shear rivet	-	-	-	-	GU66468115	2	
21	Lock hardware kit	-	-	-	-	GU31736881	1	

		NEVADA CLUB 750 1998-2001		GU018	00	TAB N.	29	
MAGNETI MARELLI IGNITION UNIT								
								
Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	ECU MED 501A	-	-	-	-	GU31721465	1	
2	Holder	-	-	-	-	GU20723820	1	
3	Screw	-	-	-	-	GU98230622	2	
4	Anti-vibration plate	-	-	-	-	GU19025300	2	
5	Pipe switch.box tosuction lugs	-	-	-	-	GU20108120	1	
6	Phase/revolution sensor	-	-	-	-	GU20721610	1	
7	Flange	-	-	-	-	GU31722065	1	
8	Screw	-	-	-	-	GU98620222	2	
9	Washer	-	-	-	-	GU95004205	2	
10	HT coil	-	-	-	-	GU30716500	2	
11	Coil holder	-	-	-	-	GU20716720	2	
12	Screw	-	-	-	-	GU98610125	4	
13	Washer	-	-	-	-	GU95004204	4	
14	Nut M4x0,7	-	-	-	-	GU92630104	4	
15	Screw	-	-	-	-	GU98620360	2	
16	Washer 6,15x11x0,8	-	-	-	-	GU95004206	4	
17	Nut M6x1	-	-	-	-	GU92630106	2	
18	Cap	-	-	-	-	GU14717600	2	
19	HT cable	-	-	-	-	GU17718350	2	
20	Sparkplug cap NGK	-	-	-	-	GU30717410	2	
21	Spark plug NGK BR8ES	-	-	-	-	GU31717061	2	
22	Relay Siemens A302/B1008	-	-	-	-	GU30732560	1	
23	Hose clamp D9	-	-	-	-	GU61108500	3	
24	Rubber spacer	-	-	-	-	GU91551080	2	
25	Spacer	-	-	-	-	GU91180608	2	
26	Washer	-	-	-	-	GU95000206	2	
27	Nut M6x1	-	-	-	-	GU92630206	2	
28	Washer	-	-	-	-	GU95100120	4	




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Crankshaft cpl.	1-X-Y	-	-	02399N- DU	-	GU31064165	1
	Crankshaft cpl.	W	-	-	-	-	GU27064185	1
2	Plug	-	-	-	-	-	GU19065400	1
3	Connecting rod cpl.	-	-	-	-	-	GU27061585	2
4	Screw	-	-	-	-	-	GU19062261	4
6	Bearing half-shell	-	-	-	-	-	GU27062060	4
7	Front main half-bearing	-	-	-	-	-	GU27065660	2
8	Rear main half-bearing	-	-	-	-	-	GU27066560	2
9	Half-clamp	-	-	-	-	-	GU27066460	2
10	Piston assy	-	-	-	00700N	-	GU20060220	2
11	Slot piston ring	-	-	-	-	-	GU19060763	2
12	Scraper ring	-	-	-	-	-	GU19061063	2
13	Piston pin	-	-	-	-	-	GU27061285	2
14	Stop ring	-	-	-	-	-	GU27061385	4
15	Slot piston ring	-	-	-	-	-	GU27060860	2
16	Pistonring set	-	-	-	-	-	GU31060616	2
17	Bush	-	-	-	-	-	GU27061885	2
18	Screw	-	-	-	-	-	GU19067700	6
19	Washer 8,4X13X0,8	-	-	-	-	-	GU14615901	6




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Carburettor RH	-	-	D	-	GU31112672	1	
	Carburettor RH PHBH 30 BD	1-Y	-	-	00700N-T1	GU31112688	1	
	Carburettor RH	W-X	-	-	LF	GU31112666	1	
2	Carburettor LH	W-X	-	-	LF	GU31112667	1	
	Carburettor LH	-	-	D	-	GU31112673	1	
	Carburettor LH PHBH 30 BS	1-Y	-	-	00700N-T1	GU31112689	1	
3	RH intake manifold	-	-	-	-	GU20115020	1	
4	LH intake manifold	-	-	-	-	GU20115021	1	
5	Gasket	-	-	-	-	GU19115580	2	
6	Screw	-	-	-	-	GU98310610	2	
7	Washer 6,25x10x1,5	-	-	-	-	GU95100116	2	
8	Hex socket screw M6X25	-	-	-	-	GU98622325	4	
9	Special washer	-	-	-	-	GU61013800	4	
10	Hose	-	-	-	-	GU19114360	2	
	Sleeve with hole D.15,5 mm	-	-	D	-	GU31114060	2	
11	Hose clamp 32X52X8	-	-	-	-	GU93305032	4	
12	Gasket ring	-	-	-	-	GU19114680	2	
13	Air intake hose	-	-	-	-	GU19114460	2	
14	Hose clamp	-	-	-	-	GU19718000	2	
15	Hose clamp	-	-	-	-	GU93305031	4	

	NEVADA CLUB 750 1998-2001	GU018	00	TAB N.	<b>32</b>
	<b>DUCATI GENERATOR</b>				




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Generator	1-X-Y	-	-	02399N	-	GU37712405	1
2	Voltage regulator	1-X-Y	-	-	02399N	-	GU37703805	1
3	Washer 16,25x24,5x5	1-X-Y	-	-	02399N	-	GU30714201	1
4	Nut M16X1,5	1-X-Y	-	-	02399N	-	GU92603516	1
5	Front calotte	1-X-Y	-	-	02399N	-	GU29711460	1
6	Screw	1-X-Y	-	-	02399N	-	GU98620265	3
7	Washer 5,9X3X0,8	1-X-Y	-	-	02399N	-	GU29217960	3
8	Support plate	1-X-Y	-	-	02399N	-	GU29704060	1
9	Spacer	1-X-Y	-	-	02399N	-	GU31712365	1
10	Transmission key	1-X-Y	-	-	02399N	-	GU91600450	1
11	Rear cap	1-X-Y	-	-	02399N	-	GU29711960	1
12	Hex socket screw M6X16	1-X-Y	-	-	02399N	-	GU98622316	2
13	Washer	1-X-Y	-	-	02399N	-	GU95001206	2
14	Captive nut	1-X-Y	-	-	02399N	-	GU92660601	2




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Primary gear shaft Z=11	-	-	-	-	GU23210570	1	
2	Gear 5a AP Z=20	-	-	-	-	GU23212070	1	
3	Thrust washer	-	-	-	-	GU19215460	3	
4	Circlip	-	-	-	-	GU90271127	2	
5	Gear 4a AP Z=18	-	-	-	-	GU19211861	1	
6	Gear 3a AP Z=18	-	-	-	-	GU19211460	1	
7	Roller cage	-	-	-	-	GU92251023	1	
8	Gear 2a AP Z=14	-	-	-	2A	GU23211372	1	
	Gear 2a AP Z=14	-	-	-	1A	GU19211361	1	
9	Washer	-	-	-	-	GU19218062	2	
10	Bearing AP 17x40x17,5	-	-	-	-	GU92218417	1	
11	Clearance washer	-	-	-	-	GU19214660	4	
12	Nut	-	-	-	-	GU10054100	1	
13	Bearing AP 20x37x17	-	-	-	-	GU92230320	1	
14	Driven shaft	-	-	-	-	GU19213661	1	
15	Spacer	-	-	-	-	GU19212900	1	
16	Bearing 20X47X14	-	-	-	-	GU92201220	1	
17	Spacer	-	-	-	-	GU19213720	1	
18	Gasket ring 18,77X1,78	-	-	-	-	GU90706188	1	
19	Circlip	-	-	-	-	GU90271121	1	
20	Gear 2a AS Z=23	-	-	-	1A	GU23214571	1	
	Gear 2a AS Z=23	-	-	-	2A	GU23214572	1	
21	Gear 3a AS Z=23	-	-	-	-	GU19214860	1	
22	Gear 4a AS Z=19	-	-	-	-	GU19215161	1	
23	Gear 5a AS Z=18	-	-	-	-	GU23215270	1	
24	Gear 1a AS Z=26	-	-	-	-	GU23214071	1	
25	Washer	-	-	-	-	GU19218061	2	
26	Bearing	-	-	-	-	GU92234716	1	
27	Spacer 1,5 mm	-	-	-	-	GU10214300	1	
	Spacer 1,7 mm	-	-	-	-	GU10214301	1	
	Spacer 1,8 mm	-	-	-	-	GU10214302	1	
	Spacer 1,9 mm	-	-	-	-	GU10214303	1	
	Washer 2 mm	-	-	-	-	GU10214304	1	

	Spacer 2,1 mm	-	-	-	-	-	GU10214305	1
28	Gutter	-	-	-	-	-	GU23202074	1
29	Circlip	-	-	-	-	-	GU90271117	1
30	Shift cam	-	-	-	-	-	GU19234420	1
31	Pin	-	-	-	-	-	GU19234600	4
32	Spacer 1 mm	-	-	-	-	-	GU19355300	1
33	Snap ring	-	-	-	-	-	GU90271020	1
34	Fork AP	-	-	-	-	-	GU19231220	1
35	Fork AS	-	-	-	-	-	GU19231020	2
36	Roller	-	-	-	-	-	GU92297909	3
37	Pin	-	-	-	-	-	GU95520316	3
38	Preselection complete	-	-	-	-	-	GU20236220	1
39	Spring	-	-	-	-	-	GU28238261	1
40	Spacer	-	-	-	-	-	GU20208520	1
41	Idle gear	-	-	-	-	-	GU27211160	1
42	Nut	-	-	-	-	-	GU10054100	1
43	Clearance washer	-	-	-	-	-	GU39238100	1
44	Pre-selector kit	-	-	-	-	-	GU20999520	1




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Gas valve 50	1-Y	-	-	00700N-T1	-	GU19934880	2
	Gas valve 40	W-X	-	-	LF	-	GU19934860	2
2	Conical pin 8	W-X	-	-	LF	-	GU19934960	2
	Conical pin X88-4a	1-Y	-	-	00700N-T1	-	GU31937788	2
3	Needle valve 266t	W-X	-	-	LF	-	GU31935515	2
	Needle valve 262T	-	-	D	-	-	GU31935561	2
	Needle valve 264 T1	1-Y	-	-	00700N-T1	-	GU31935588	2
4	Main jet 102	W-X	-	-	LF	-	GU19935700	2
	Main jet 105	1-Y	-	-	00700N-T1	-	GU19935750	2
5	Idle jet 40	-	-	D	-	-	GU19935900	2
	Idle jet 38	W-X	-	-	LF	-	GU27935960	2
	Idle jet 32	1-Y	-	-	00700N-T1	-	GU31935988	2
6	Starter jet 60	-	-	-	-	-	GU19936000	2
7	Needle valve	-	-	-	-	-	GU19934600	2
8	Float gr.9,5	-	-	-	-	-	GU27934315	2
10	Wire tensioner screw	-	-	-	-	-	GU12937200	4
11	Screw	-	-	-	-	-	GU14934650	2
12	Cover	-	-	-	-	-	GU19935080	2
13	Gas valve return spring	-	-	-	T2	-	GU19937180	2
	Gas valve return spring	-	-	-	01101N-T3	-	GU31937188	2
14	Plate	-	-	-	-	-	GU19938580	2
15	Conical pin clip	-	-	-	-	-	GU65933600	2
18	Float chamber fix.plug	-	-	-	-	-	GU27933720	2
19	Gaskets set	-	-	-	-	-	GU19939980	1
21	Screw	-	-	-	-	-	GU13937900	2
22	Starter device cover	-	-	-	-	-	GU17937450	2
24	Valve spring	-	-	-	-	-	GU39937600	2
25	Starter valve	-	-	-	-	-	GU13937800	2
26	Adj.min.eng.speed screw	-	-	-	-	-	GU13936200	2
27	Spring	-	-	-	-	-	GU13936300	2

28	Flat washer	-	-	-	-	-	GU65933700	2
30	Gas valve adjuster screw	-	-	-	-	-	GU13936600	2
31	Spring	-	-	-	-	-	GU13936700	2
32	Flat washer	-	-	-	-	-	GU14931650	2
35	Fuel filter	-	-	-	-	-	GU43934000	2
36	Fuel pipe union cap	-	-	-	-	-	GU31934680	2
37	Gasket	-	-	-	-	-	GU13934700	2
38	Cap fixing screw	-	-	-	-	-	GU10934900	2
41	Aluminium float chamber	-	-	-	-	-	GU19934480	2
	Float chamber plastica	-	-	-	03399N	-	GU31934460	2
42	Float pin	-	-	-	-	-	GU13933100	2
43	Breather pipe	-	-	-	-	-	GU95985351	2





Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Crankcase, grey	-	-	-	-	GU20000320	1	
2	Stud bolt	-	-	-	-	GU96451560	4	
3	Stud bolt	-	-	-	-	GU96451430	4	
4	Stud bolt	-	-	-	-	GU96508055	2	
5	Bush	-	-	-	-	GU19015020	4	
6	Spring washer 8x15x0,3	-	-	-	-	GU61270300	6	
7	Nut M8X1,25	-	-	-	-	GU92602208	6	
8	Union	-	-	-	-	GU19003800	1	
9	Bush 6,6x9x13	-	-	-	-	GU19002020	2	
10	Plug	-	-	-	-	GU19016320	1	
11	Gasket ring	-	-	-	-	GU90401530	1	
12	Screw M6X30	-	-	-	-	GU98620330	2	
13	Gasket ring	-	-	-	M2	GU04000500	1	
	Gasket ring	-	-	-	M1	GU90405367	1	
14	Cover grey	-	-	-	-	GU31001480	1	
15	Gasket	-	-	-	-	GU19001200	1	
16	Hex socket screw M6X25	-	-	-	-	GU98622325	22	
17	Rubber spacer	-	-	-	-	GU19007700	1	
18	Gasket ring 28x38x7	-	-	-	-	GU90402840	1	
19	Oil sump grey	-	-	-	-	GU20003510	1	
20	Gasket	-	-	-	-	GU19003602	1	
21	Oil unload plug M10X1	-	-	-	-	GU31003766	1	
22	Gasket	-	-	-	-	GU10528900	1	
23	Hex socket screw M6X18	-	-	-	-	GU98622318	5	
24	Cover	-	-	-	-	GU27001636	1	
25	Flange	-	-	-	-	GU27001136	1	
26	Cover, grey	-	-	-	-	GU20003410	1	
27	O-ring	-	-	-	-	GU90706444	1	
28	Oil load plug	-	-	-	-	GU27004985	1	
29	Gasket ring	-	-	-	-	GU90706282	1	
30	Oil unload plug	-	-	-	-	GU12003702	1	
31	Gasket 20,1x28x2	-	-	-	-	GU95100709	1	
32	Bolt	-	-	-	-	GU27152885	1	

33	Gasket 8,25x15x1	-	-	-	-	-	GU12154200	1
34	Oil seals - set	-	-	-	-	-	GU31999565	1
35	Gasket set	-	-	-	-	-	GU27999060	1
36	Column nut	-	-	-	-	-	GU13021900	4
37	Washer 10,5X18X0,8	-	-	-	-	-	GU95129180	4
38	Engine w/o gearbox	-	-	-	-	-	GU27991026	1





Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	RH cylinder head grey	-	-	-	-	GU20022120	1	
2	LH cylinder head grey	-	-	-	-	GU20022220	1	
3	Valve guide	-	-	-	-	GU61036801	4	
4	Snap ring	-	-	-	-	GU90353009	4	
5	Stud bolt	-	-	-	-	GU96506042	4	
6	Anti-vibration plate	-	-	-	-	GU19025300	4	
7	Nut	-	-	-	-	GU19021920	2	
8	Oil seal	-	-	-	-	GU19037820	4	
9	Valves cover, stain.	-	-	-	-	GU31023500	2	
10	Gasket	-	-	-	-	GU19023700	2	
11	Nut M10X1,5	-	-	-	-	GU92603010	4	
12	Column nut	-	-	-	-	GU13021900	4	
13	Washer 10,5X18X0,8	-	-	-	-	GU95129180	4	
14	Stud bolt M10x214	-	-	-	-	GU96510214	4	
15	Stud bolt M10x182	-	-	-	-	GU96510181	4	
16	Hex socket screw M6X25	-	-	-	-	GU98622325	10	
17	Cylinder with piston, grey	-	-	-	-	GU20060120	2	
18	Bush	-	-	-	-	GU19021360	2	
19	Gasket	-	-	-	-	GU27022060	2	
20	Stud bolt M8x143	-	-	-	-	GU96508145	2	
21	Spring washer 8x15x0,3	-	-	-	-	GU61270300	2	
22	Plug	-	-	-	-	GU93180245	4	
23	O-ring	-	-	-	-	GU61027200	2	
24	Gasket	-	-	-	-	GU27020820	2	
25	Spacer	-	-	-	-	GU19032980	4	
26	O-ring	-	-	-	-	GU90706076	2	

	NEVADA CLUB 750 1998-2001	GU018	00	TAB N.	<b>37</b>
	<b>STARTER MOTOR COVER</b>				




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Motor cover assy chr.plated	-	-	-	-	GU03733200	1	
2	Starter device cover	-	-	-	-	GU03733300	1	
3	Decal "Aquila"	-	-	-	-	GU01517700	1	
4	Rubber spacer	-	-	-	-	GU93180577	1	
5	Cap nut	-	-	-	-	GU92781053	1	
6	Plate	-	-	-	-	GU03436300	1	
7	Insulating spacer	-	-	-	-	GU03733000	1	
8	Hose clamp	-	-	-	-	GU03733400	1	
9	Screw M5x18	-	-	-	-	GU03733500	1	
10	Gasket PVC	-	-	-	-	GU00823931080	1	


		NEVADA CLUB 750 1998-2001	GU018	00	TAB N.	38		
TIMING SYSTEM								
								
Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Intake valve	-	-	-	-	GU19036082	2	
2	Exhaust valve	-	-	-	-	GU19036183	2	
4	Spring	-	-	-	-	GU27037521	4	
5	Upper cup	-	-	-	-	GU31038015	4	
6	Half-cone	-	-	-	-	GU61038100	8	
7	Rocker arm assy.	-	-	-	-	GU19030500	4	
8	Screw	-	-	-	-	GU19034000	4	
9	Nut M6x1	-	-	-	-	GU92602406	4	
10	Rocker shaft	-	-	-	-	GU19032080	2	
11	Thrust washer	-	-	-	-	GU19032380	4	
12	Circlip	-	-	-	-	GU90271018	4	
13	Lower cup	-	-	-	-	GU31037015	4	
14	Spacer	-	-	-	-	GU19032980	4	
15	Hose	-	-	-	-	GU19027500	2	
16	Camshaft	1-Y	-	-	00700N-T1	GU27053464	1	
	Camshaft	W-X	-	-	LF	GU27053463	1	
17	Timing system gear	-	-	-	-	GU19054521	1	
18	Bolt	-	-	-	-	GU61054900	2	
19	Camshaft chain	-	-	-	-	GU19058021	1	
20	Chain stretching drive	-	-	-	-	GU19058220	1	
21	Screw	-	-	-	-	GU98822316	1	
22	Washer	-	-	-	-	GU95129115	1	
23	Sector	-	-	-	-	GU19055700	2	
24	Snap ring	-	-	-	-	GU90353029	1	
25	Tappet	-	-	-	-	GU19045861	4	
26	Rocker arm rod	-	-	-	-	GU31045015	4	
27	Cap	-	-	-	-	GU27045420	4	
28	Safety washer	-	-	-	-	GU23217800	2	


MOTO GUZZI		NEVADA CLUB 750 1998-2001	GU018	00	TAB N.	39		
CLUTCH								
Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Clutch AP	-	-	-	-	GU27080160	1	
2	New cup type	-	-	-	-	GU19083462	1	
3	Snap ring	-	-	-	-	GU90272075	1	
4	Driven clutch disc	-	-	-	-	GU27084460	1	
5	Chain ring Digiplex	-	-	-	-	GU31067965	1	
6	Washer 6,4x10x0,7	-	-	-	-	GU14217901	6	
7	Hex screw M6X16	-	-	-	-	GU98054316	6	
8	Rod	-	-	-	-	GU20085720	1	
9	Inner body	-	-	-	-	GU14086000	1	
10	Thrust bearing	-	-	-	-	GU12087001	1	
11	Outer body	-	-	-	-	GU14086100	1	
12	O-ring 17,13x2,62	-	-	-	-	GU90706170	1	
13	Clutch release shaft	-	-	-	-	GU14090201	1	
14	Adjuster screw	-	-	-	-	GU14090400	1	
15	Nut M8X1	-	-	-	-	GU92602508	1	
16	Lever return spring	-	-	-	-	GU94321105	1	
17	Pin 7x39	-	-	-	-	GU95780271	1	
18	Split pin	-	-	-	-	GU95500222	1	
19	Gasket ring	-	-	-	-	GU90403245	1	
20	Transmission shaft Z=16	-	-	-	-	GU27210760	1	
21	Gasket ring 6x16x7	-	-	-	-	GU90400616	1	
22	Spacer	-	-	-	-	GU19213760	1	
23	O-ring 23,52x1,78	-	-	-	-	GU90706235	1	
24	Nut	-	-	-	-	GU19356760	1	
25	Nut M8X1,25	-	-	-	-	GU92602208	1	
26	Clutch housing, grey DIGIP.	-	-	-	-	GU31200480	1	
27	Plug	-	-	-	-	GU93180220	1	
28	Bearing 25x52x15	-	-	-	-	GU92201225	1	
29	Bearing fixing plate	-	-	-	-	GU19203460	1	
30	Screw	-	-	-	-	GU98054314	3	
31	Washer 6,4x10x0,7	-	-	-	-	GU14217901	3	
32	Screw M6X30	-	-	-	-	GU98620330	11	
33	Screw M8X35	-	-	-	-	GU98620435	5	
34	Screw	-	-	-	-	GU98620450	1	
35	Spring washer 8x15x0,3	-	-	-	-	GU61270300	6	
36	Oil unload plug M10X1	-	-	-	-	GU31003766	1	
37	Washer 10,2x18x2	-	-	-	-	GU95004210	1	

MOTO GUZZI		NEVADA CLUB 750 1998-2001	GU018	00	TAB N.	40		
EXHAUST UNIT								
Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	RH exhaust pipe	-	-	-	CAT	GU31120762	1	
	RH exhaust pipe	-	-	-	02101N-CAT-T6	GU31120764	1	
	RH exhaust pipe	-	-	-	-	GU31120760	1	
2	LH exhaust pipe	-	-	-	-	GU31120761	1	
	LH exhaust pipe	-	-	-	CAT	GU31120763	1	
	LH exhaust pipe	-	-	-	02101N-CAT-T6	GU31120765	1	
3	Expansion chamber	-	-	-	-	GU31123960	1	
4	Hose clamp	-	-	-	-	GU31126960	2	
5	Gasket	-	-	-	-	GU19025280	2	
6	Spacer	-	-	-	-	GU19025460	4	
7	Exhaust ring nut	-	-	-	-	GU19121050	2	
	Ring nut	-	-	-	03401N-T9	GU31121081	2	
8	Special washer	-	-	-	-	GU61013800	4	
9	Nut	-	-	-	03401N-T8	GU31121880	4	
	Nut	-	-	-	-	GU92701062	4	
10	LH silencer	-	-	-	-	GU31123060	1	
	LH silencer	-	-	-	CAT	GU31123062	1	
11	RH silencer	-	-	-	CAT	GU31122962	1	
	RH silencer	-	-	-	-	GU31122960	1	
12	Hose clamp	-	-	-	CAT	GU30123430	2	
	Hose clamp	-	-	-	-	GU31123460	2	
13	RH plate	-	-	-	-	GU31128660	1	
14	LH plate	-	-	-	-	GU31128760	1	
15	Spring washer 8x15x0,3	-	-	-	-	GU61270300	6	
16	Nut	-	-	-	-	GU92781081	4	
17	Screw	-	-	-	-	GU98622420	2	
18	Washer 8,4X13X0,8	-	-	-	-	GU14615901	2	
19	Nut	-	-	-	-	GU92660008	2	
20	Screw	-	-	-	-	GU61127520	2	
21	Ring nut	-	-	-	-	GU61127220	2	
22	Plug	-	-	-	-	GU23943410	2	
23	Silencer protection	-	-	-	CAT	GU31121962	2	
24	Special washer	-	-	-	CAT	GU61013800	4	
25	Screw	-	-	-	CAT	GU98230606	4	




Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Gear lever	-	-	-	-	GU31250960	1	
2	Rubber spacer	-	-	-	-	GU14251001	1	
3	Spring washer	-	-	-	-	GU95129260	1	
4	O-ring	-	-	-	-	GU90706141	2	
5	Lever	-	-	-	-	GU28256960	1	
6	Screw	-	-	-	T2	GU98052325	2	
	Screw M6X22	-	-	-	01101N-T3	GU98632322	2	
7	Special washer	-	-	-	-	GU61013800	2	
8	Gearbox linkage rod	-	-	-	-	GU31257880	1	
9	Fork	-	-	-	T2	GU28258160	3	
	Ball joint	-	-	-	01101N-T3	GU31258181	3	
10	Nut	-	-	-	-	GU92602206	4	
11	Fork	-	-	-	-	GU31626880	1	
12	Lever	-	-	-	-	GU31256960	1	
13	Bush	-	-	-	-	GU17252050	1	
14	Pin	-	-	-	-	GU31252360	1	
15	Pin	-	-	-	-	GU95770265	1	
16	Washer	-	-	-	-	GU95129110	1	
17	Split pin	-	-	-	-	GU95500222	1	
18	Nut	-	-	-	-	GU92630508	1	
19	Shift lever	-	-	-	-	GU19258220	1	
20	Special washer	-	-	-	-	GU61013800	3	
21	Nut M6x1	-	-	-	-	GU92630106	3	
22	Tie rod	-	-	-	-	GU18257950	1	
23	Gearbox linkage rod	-	-	-	-	GU96506040	1	
24	Washer	-	-	-	-	GU95004208	1	

MOTO GUZZI		NEVADA CLUB 750 1998-2001	GU018	00	TAB N.	42				
		STARTER MOTOR								
										
Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.		
1	Starter motor Valeo	-	-	-	-	GU30730711	1			
3	Pinion assy	-	-	-	-	GU30530510	1			
4	Brush revision set	-	-	-	-	GU30530511	1			
9	Starter motor revision kit	-	-	-	-	GU30530512	1			
10	Screw M8X35	-	-	-	-	GU98620435	2			
11	Washer	-	-	-	-	GU95004208	2			



Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Oil pump	-	-	-	-	GU19146422	1	
3	Roller bearing 10x22x20	-	-	-	-	GU92252210	1	
4	Oil pump shaft assy.	-	-	-	-	GU20147810	1	
5	Inner rotor	-	-	-	-	GU20148410	1	
6	Outer rotor	-	-	-	-	GU20148610	1	
7	Roller	-	-	-	-	GU92296723	1	
8	Pressure sensor	-	-	-	02201N	GU31999581	1	
9	Screw M6X35	-	-	-	-	GU98620335	3	
10	Pin	-	-	-	-	GU19018920	2	
11	Oil filter	-	-	-	-	GU19152200	1	
12	Screw	-	-	-	-	GU98054314	1	
13	Plate	-	-	-	-	GU95187006	1	
14	Oil filter	-	-	-	-	GU27153085	1	
15	Oil pressure valve	-	-	-	-	GU31158250	1	
16	Washer 18,25x24x1	-	-	-	-	GU18144350	1	
17	Pump gear	-	-	-	-	GU20147710	1	
18	Washer 10,5x16x1	-	-	-	-	GU19149800	1	
19	Nut M10x1,25	-	-	-	-	GU92602510	1	
20	Plug	-	-	-	-	GU31016050	1	
21	Gasket 14,25	-	-	-	-	GU18161150	1	
22	O-ring	-	-	-	-	GU90706111	1	
23	Washer 6,15x11x0,8	-	-	-	-	GU95004206	1	



Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Gearbox cover, grey	-	-	-	-	GU31200880	1	
2	Bearing 15x35x11	-	-	-	-	GU92204215	2	
3	Gasket ring 28x40x7	-	-	-	-	GU90402841	1	
4	O-ring 13,95x2,92	-	-	-	-	GU90706140	1	
5	Plate	-	-	-	1A	GU23213870	1	
	Plate	-	-	-	2A	GU23213872	1	
6	Screw	-	-	-	-	GU98622314	4	
7	Washer 6,4x10x0,7	-	-	-	-	GU14217901	6	
8	Plate	-	-	-	-	GU19235800	1	
9	Screw	-	-	-	-	GU98622314	2	
10	Gasket	-	-	-	-	GU23200370	1	
11	Sensor	-	-	-	-	GU19207220	1	
12	Gasket 8,25x15x1	-	-	-	-	GU12154200	1	
13	Screw M12x1,25	-	-	-	-	GU19237800	1	
14	Low nut M12x1,25	-	-	-	-	GU92602512	1	
15	Gasket	-	-	-	-	GU19201120	1	
16	Bush 6,6x9x13	-	-	-	-	GU19002020	4	
17	Gearbox, grey	-	-	-	-	GU31200280	1	
18	Screw M6X30	-	-	-	1A	GU98620330	5	
	Screw M6X35	-	-	-	2A	GU98620335	2	
19	Screw M8X35	-	-	-	-	GU98620435	4	
20	Pawl	-	-	-	-	GU55234700	1	
21	Lever return spring	-	-	-	-	GU94321067	1	
22	Breather plug	-	-	-	-	GU19206501	1	
23	Gasket	-	-	-	-	GU10528900	2	
24	Oil plug	-	-	-	-	GU12022600	1	
25	O-ring 20,24X2,62	-	-	-	-	GU90706203	1	
26	Oil unload plug M10X1	-	-	-	-	GU31003766	1	
27	Oil bulhead	-	-	-	1A	GU19208220	1	
	Oil bulhead	-	-	-	2A	GU23208272	1	
28	Ball bearing 20x42x12	-	-	-	-	GU92201120	1	
29	Bush 10,25x15,7x8	-	-	-	-	GU19202320	2	
30	Transmission assy and housing	-	-	-	-	GU27991561	1	